Cambium PMP Synchronization Solutions User Guide

January 2017 V007.001



Accuracy

While reasonable efforts have been made to assure the accuracy of this document, Cambium Networks assumes no liability resulting from any inaccuracies or omissions in this document, or from use of the information obtained herein. Cambium reserves the right to make changes to any products described herein to improve reliability, function, or design, and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Cambium does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others. It is possible that this publication may contain references to, or information about Cambium products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Cambium intends to announce such Cambium products, programming, or services in your country.

Copyrights

This document, Cambium products, and 3rd Party software products described in this document may include or describe copyrighted Cambium and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Cambium, its licensors, and other 3rd Party supplied software certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Cambium, its licensors, or the 3rd Party software supplied material contained in the Cambium products described in this document may not be copied, reproduced, reverse engineered, distributed, merged or modified in any manner without the express written permission of Cambium. Furthermore, the purchase of Cambium products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Cambium or other 3rd Party supplied software, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

Restrictions

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Cambium.

License Agreements

The software described in this document is the property of Cambium and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

High Risk Materials

Components, units, or 3rd Party products used in the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: the operation of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (High Risk Activities). Cambium and its supplier(s) specifically disclaim any expressed or implied warranty of fitness for such High Risk Activities.

© 2017 Cambium Networks Limited. All Rights Reserved.

Safety and regulatory information

This section describes important safety and regulatory guidelines that must be observed by personnel installing or operating Cambium wireless equipment.

Important safety information



To prevent loss of life or physical injury, observe the safety guidelines in this section.

Power lines

Exercise extreme care when working near power lines.

Working at heights

Exercise extreme care when working at heights.

Grounding and protective earth

Units must be properly grounded to protect against lightning. It is the user's responsibility to install the equipment in accordance with national regulations. In the USA, follow Section 810 of the *National Electric Code, ANSI/NFPA No.70-1984* (USA). In Canada, follow Section 54 of the *Canadian Electrical Code.* These codes describe correct installation procedures for grounding the outdoor unit, mast, lead-in wire and discharge unit, size of grounding conductors and connection requirements for grounding electrodes. Other regulations may apply in different countries and therefore it is recommended that installation of the outdoor unit be contracted to a professional installer.

Powering down before servicing

Always power down and unplug the equipment before servicing.

Primary disconnect device

The AP, SM, or BHs unit's power supply is the primary disconnect device.

External cables

Safety may be compromised if outdoor rated cables are not used for connections that will be exposed to the outdoor environment.

RF exposure near the antenna

Radio frequency (RF) fields will be present close to the antenna when the transmitter is on. Always turn off the power to the unit before undertaking maintenance activities in front of the antenna.

Minimum separation distances

Install the AP/SM/BH so as to provide and maintain the minimum separation distances from all persons.

The minimum separation distances for each frequency variant are specified in the product's corresponding User Guide.

Contents

Safety and regulatory information	i
Important safety information	i
General information	X
Version information	X
Contacting Cambium Networks	X
Caring for the environment	xi
Chapter 1: Introduction to synchronization	1-1
Interference and reliability	1-2
Exclusivity and free use of spectrum	1-2
Sources of interference	1-3
Neutralizing interference	1-4
GPS synchronization	1-4
Configuration options for TDD synchronization	1-5
Alternative to GPS synchronization	1-6
Cambium's synchronization solutions	1-7
Universal GPS (UGPS)	1-7
CMM5	1-8
CMM4 (Rack Mount)	1-8
CMM4 (Cabinet with switch)	1-9
CMM4 (Cabinet without switch)	1-9
CMMmicro (CMM3) - Product is End of Life and no longer available for new	w shipments1-10
Chapter 2: Cambium Cluster Management Module (CMM5)	
Product Overview	2-12
Cluster Management: Scenario 1	2-12
Cluster Management: Scenario 2	2-13
CMM5 Controller Module	
CMM5 Injector Module	2-15
CMM5 Injector Compatibility Matrix	2-15
CMM5 Specifications	
240 Watt Power Supply	2-17
600 Watt Power Supply	2-18
Power Supply Selection (When to use Each One)	2-18
Power Line Filter	
Ferrite Beads	2-19
What's in Each Box	2-20
Providing Sync to CMM5 via uGPS Module	
CMM5 Planning	2-22

Injector Cabling	2-22
Controller Cabling	2-22
CMM5 Application Scenario: Single Injector (No Controller)	2-23
CMM5 Application Scenario: Single Injector and Controller	2-24
CMM5 Application Scenario: Dual Injectors with Controller	2-25
CMM5 Injector Initial Startup	2-27
Injector Initial Startup	2-27
CMM5 Controller Initial Startup	2-27
Controller Initial Startup	2-28
CMM5 Controller Configuration	2-28
Log In	2-28
Reset Password	2-29
View System Status	2-29
View Network -Interface Status	2-30
View Synchronization Status	2-32
View Chassis Status	2-32
Identify a Chassis	2-33
View Port Status	2-35
View/Configure Static Routes	2-36
Configure a New IP Address	2-37
Set Local Time/NTP Protocol	
Update Injector Firmware	2-39
Update Controller Firmware	2-40
Installing the CMM5	2-42
Avoiding Hazards	2-42
Grounding Equipment	2-42
Conforming to Regulations	2-43
Protecting Cables and Connections	2-43
Testing the Components	2-43
Unpacking Components	2-43
Installing a uGPS Antenna	2-43
Installing a Single Controller	2-44
Installing a Single Injector	2-45
Installing Two Injectors side by side	2-47
Installing a Controller/Injector side by side	2-48
Installing a 600 Watt Power Supply	2-49
Installing a Split DC Power Line	2-52
Cabling the CMM5	2-53
Class A Emissions Requirements	2-57
Chapter 3: Cambium Cluster Management Module (CMM4)	3-1
CMM4 and Controller Board	3-2
Power	3-6
Ethernet Switch	3-7

Specifications	3-8
Providing sync to CMM via UGPS Module	3-10
CMM Planning	3-11
Typical Ethernet Cabling	3-11
Standard Ethernet Cabling Configuration	3-11
Power Planning	3-16
Syncing Two Co-located CMMs Together	3-18
Cables	3-20
EtherWAN Switch Information	3-24
Configuring a CMM4	3-26
Configuring IP Communications Parameters	3-26
Overriding Forgotten IP Addresses, Usernames, or Passwords	3-27
Log In	3-30
User Update	3-31
Add User	3-32
Delete User	3-33
Configuring the CMM4 ports	3-33
Configuring General CMM4 Parameters	3-34
Configuring the SNMP parameters	3-36
Configuring VLAN	3-39
Configuring the Unit Settings	3-40
Viewing the ARP Table (Statistics)	3-41
Viewing General Status	3-42
Viewing Sync Status	3-45
Viewing the System Log	3-46
Viewing the Network Interface	3-47
Viewing Layer 2 neighbors	3-47
Installing a CMM4	3-48
Avoiding hazards	3-48
Grounding Equipment	3-48
Conforming to Regulations	3-49
Protecting Cables and Connections	3-49
Testing the Components	3-49
Unpacking Components	3-49
Cables	3-49
Installing a GPS Antenna	3-49
Installing the power supply for the CMM4 (30 VDC or 54 VDC)	3-53
Temperature Range	3-58
Installing a CMM4 (Models 1090CKHH and 1091HH)	3-58
Installing a Rackmount CMM4 (Model 1092HH)	3-60
Cabling a CMM4 (Models 1090CKHH and 1091HH)	3-61
Cabling a Rackmount CMM4	3-66
Power Faults	3-68

Chapter 4:	Universal Global Positioning System Module	4-1
UGPS Pr	oduct Description and Overview	4-2
UGPS Po	ower Source Configurations	4-4
Exter	rnal Power Only	4-4
Powe	er from the Radio via UGPS Timing Port 1 or UGPS Timing Port 2	4-8
UGPS an	nd CMM Configurations	4-14
Product S	Specifications	4-15
UGPS in	stallation and operation	4-16
UGPS Ins	stallation Procedure	4-18
IP defaul	t bypass	4-22
GPS state	us and location data readout	4-25
Retri	eving GPS Status and Location Data via Radio Web Management G	UI 4-25
Retri	eving GPS status and location data via SNMP	4-26
UGPS Po	ower Port and Timing Port Pinouts	4-29
Chapter 5:	CMM Regulatory and Legal Notices	5-1
Impo	ortant Note on Modifications	5-1
National	and Regional Regulatory Notices	5-2
U.S.	Federal Communication Commission (FCC) Notification	5-2
Indu	stry Canada (IC) NotificationErr	or! Bookmark not defined.
Equi	pment Disposal	5-2
EU D	Declaration of Conformity for RoHS Compliance	5-2
Labe	ling and Disclosure Table for China	5-3
RF Expos	sure Separation Distances	5-5
Legal No	otices	5-6
Softv	ware License Terms and Conditions	5-6
Hard	ware Warranty in U.S	5-9
Limit	t of Liability	5-9
Chapter 6:	UGPS Regulatory, Legal, and Safety Notices	6-1
IMPO	DRTANT NOTE ON MODIFICATIONS	6-1
Univ	ersal GPS module label	6-1
NAT	IONAL AND REGIONAL REGULATORY NOTICES	6-1
Equi	pment Disposal	6-2
LIMI	T OF LIABILITY	6-2

List of Figures

Figure 1 GPS Synchronization	1-4
Figure 2 One unsynchronized AP in cluster resulting in self-interference	1-6
Figure 3 CMM4 internal view, including cable glands	3-3
Figure 4 Rackmount CMM4	3-4
Figure 5 GPS Antenna	3-5
Figure 6 CMM4 Standard Configuration	3-12
Figure 7 Rackmount CMM4 Standard Configuration	3-12
Figure 8 CMM4 cabled to use Gigabit Ethernet feed	3-14
Figure 9 CMM4 cabled to support PTP 500/600	3-15
Figure 10 Location of pin 1	3-21
Figure 11 CMM sync cable pinout	3-23
Figure 12 Location of pin 1	3-23
Figure 13 IP tab of CMM4	3-26
Figure 14 Login page of CMM4	3-30
Figure 15 Changer Users Password tab of CMM4	3-31
Figure 16 Add User tab of CMM4	3-32
Figure 17 Delete User tab of CMM4	3-33
Figure 18 Port Configuration tab of CMM4	3-33
Figure 19 CMM4 Configuration tab	3-34
Figure 20 SNMP tab of CMM4	3-37
Figure 21 VLAN tab of CMM4	3-39
Figure 22 Unit Settings Tab of CMM4	3-40
Figure 23 ARP table	3-41
Figure 24 General status tab of CMM4	3-42
Figure 25 Sync Status tab of CMM4	3-45
Figure 26 System Log tab of the CMM	3-46
Figure 27 Network Interface tab of the CMM	3-47
Figure 28 Layer 2 Neighbors Log	3-47
Figure 29 Detail of GPS antenna mounting	3-50
Figure 30 Weatherproofing an N-type antenna connector	3-51
Figure 31 AP/BHM to UGPS cable	3-52
Figure 32 Power supply DC connection	3-53
Figure 33 Power supply AC connection	3-54
Figure 34 CMM4 line filter installation (EU only)	3-55
Figure 35 Rackmount CMM line filter installation (EU only)	3-56
Figure 36 Resistor when using both 56 VDC and 30 VDC power	3-58
Figure 37 CMM4 V-bracket to pole mounting	3-59

Figure 38	Attaching the rackmounting brackets	3-60
Figure 39	Rackmount CMM4 rack screws	3-61
Figure 40	Ethernet port connections	3-62
Figure 41	Staggered Ethernet cables	3-62
Figure 42	CMM4 LED indicators	3-64
Figure 43	LED indicators - rackmount CMM4	3-67
Figure 44	CMM port status showing power fault	3-68
•	UGPS connector interface	
_	Power Pinout - UGPS Ethernet Power Cable	
Figure 47	PMP 100 AP receiving synchronization from external-powered UGPS	4-5
Figure 48	PMP 320 receiving synchronization from external-powered UGPS	4-6
	One PMP 400/430 AP and one PMP 100 AP receiving synchronization from external-powere	
	Power Pinout - UGPS to AP/BHM Timing Port (6-pin RJ-11)	
•	AP/BHM to UGPS cable	
•	PTP 230 backhaul master powering UGPS and receiving synchronization	
_	PMP 450 AP powering UGPS and receiving synchronization	
•	Two PTP 230 backhaul master units powering UGPS and receiving synchronization	
•	PTP 230 backhaul master powering UGPS/receiving synchronization and PMP 100/430 recei	_
,	ronization	
_	UGPS to CMM cable pin configuration	
	Location of pin 1	4-17
•	Configuring the sync input and disabling UGPS power - PMP 100/400/430 and PTP 100/200	/ 1Q
	Configuring the sync source - PMP 320 series	
•	Configuring the sync input and enabling UGPS power - PTP 230 series	
	CMM port configuration for UGPS power	
J	IP default bypass - default radio on timing port 1	
•	IP default bypass - default radio on timing port 2	
	GPS status and location data - PMP 430 example	
	GPS status and location data - PMP 320	
_	UGPS label	
•	Waste disposal of electronic and electric equipment	
riguit 0/	vvaste disposal di ciculidilic aliu ciculic cydipiticit	0-2

List of Tables

Table 1 CMM4 model numbers and Ethernet switch configurations	3-2
Table 2 Power supply part numbers	3-6
Table 3 CMM4 specifications	3-8
Table 4 Rackmount CMM4 specifications	3-9
Table 5 Recommended Ethernet cables	3-20
Table 6 RJ-45 pinouts for straight-through Ethernet cable - 30 VDC	3-20
Table 7 RJ-45 pinouts for straight-through Ethernet cable - 56 VDC	3-21
Table 8 Recommended antenna cable	3-21
Table 9 Wire size for CMM4 DC cable	3-22
Table 10 EtherWAN switch details	3-24
Table 11 IP tab attributes	3-26
Table 12 Change User Password tab attributes	3-31
Table 13 Add User attributes	3-32
Table 14 Delete User attributes	3-33
Table 15 Port Configuration attributes	3-34
Table 16 CMM tab attributes	3-35
Table 17 Link Speed selections for CMM4	3-36
Table 18 SNMP tab attributes	3-38
Table 19 VLAN tab attributes	3-39
Table 20 Unit Settings tab attributes	3-40
Table 21 ARP Table tab attributes	3-41
Table 22 General Status tab attributes	3-43
Table 23 Sync Status tab attributes	3-45
Table 24 Network Interface tab attributes	3-47
Table 25 AP/BHM to UGPS cable pinout	3-52
Table 26 AP/BHM to UGPS cable pinout	4-9
Table 27 Compatible 30V Power Supplies and Cords	4-16
Table 28 Cable Length Specification	4-17
Table 29 UGPS IP default bypass wiring	4-22
Table 30 UGPS IP default bypass wiring	4-22
Table 31 GPS SNMP OIDs - PMP 100/400/430 and PTP 100/200/230 series	4-27
Table 32 GPS SNMP OIDs - PMP 320 series	4-28
Table 33 UGPS Power Port Pinout	4-29
Table 34 UGPS Timing Port Pinout	4-29
Table 35 Disclosure Table for China	5-3
Table 36 Exposure separation distances	5-5

General information

Version information

The following shows the issue status of this document since it was first released:

Issue	Date of issue	Remarks	
001v000	January 2013	First issue	
002v000	April 2013	Formatting updates, rack-mount power supply cabling update	
003v000	April 2013	Pinout details for UGPS powering	
004v000	Instructions for weatherproofing an N-type connector		
005v000	January 2016	Discontinue 30 VDC and 56 VDC CMM power supplies, introduce new power supplies	
		Update UGPS power supply information	
006v000	February 2016	ePMP Updates	
007v000	January 2017	Adds CMM5	

Contacting Cambium Networks

 $PMP\ support\ website: \underline{http://www.cambiumnetworks.com/support}$

Cambium main website: http://www.cambiumnetworks.com/

Sales enquiries: sales@cambiumnetworks.com
Email support: support@cambiumnetworks.com

Telephone numbers:

For full list of Cambium support telephone numbers, see: http://www.cambiumnetworks.com/support/contact-support

Address:

Cambium Networks 3800 Golf Road, Suite 360 Rolling Meadows, IL 60008

Caring for the environment

The following information describes national or regional requirements for the disposal of Cambium Networks supplied equipment and for the approved disposal of surplus packaging.

In EU countries

The following information is provided to enable regulatory compliance with the European Union (EU) directives identified and any amendments made to these directives when using Cambium equipment in EU countries.



Disposal of Cambium equipment

European Union (EU) Directive 2002/96/EC Waste Electrical and Electronic Equipment (WEEE) Do not dispose of Cambium equipment in landfill sites. In the EU, Cambium in conjunction with a recycling partner ensures that equipment is collected and recycled according to the requirements of EU environmental law.

Disposal of surplus packaging

Do not dispose of surplus packaging in landfill sites. In the EU, it is the individual recipient's responsibility to ensure that packaging materials are collected and recycled according to the requirements of EU environmental law.

In non-EU countries

In non-EU countries, dispose of Cambium equipment and all surplus packaging in accordance with national and regional regulations.

Chapter 1: Introduction to synchronization

Interference and reliability

In the unlicensed wireless environment, interference can be defined as unwanted, competing radio signals in the same frequency band. These interfering signals can disrupt, delay and reduce the reliability and quality of your network traffic and performance. In licensed frequency bands where no outside signals are competing, the issue is self-interference, i.e., your own network's signals competing with each other. In either case, the results go beyond lower quality transmission; they extend to customer dissatisfaction, loss of competitive advantage and decreased return on investment.

Exclusivity and free use of spectrum

There are two types of frequency bands in which wireless networks operate: the licensed and unlicensed bands. Characteristics of each include:

Licensed frequencies

Licensed frequencies are bands reserved for the exclusive use of a public/private entity. Since the spectrum is clean and clear with no RF emitters (controlled by other entities) operating in the same frequency, wireless system reliability is greatly improved. Interference issues are largely confined to self-interference problems.

Unlicensed frequencies

Frequently described as a "Free Use" environment, unlicensed frequencies provide spectrum that is available to virtually anyone that wants to use it. Signals from different transmitting organizations and entities may compete with one another for space, creating an environment in which interference and ambient noise — as well as self-interference — can be significant impairments to reliable communications. The sheer number of the competing signals in unlicensed spectrum places a premium on ensuring that the equipment you use is of exceptionally high quality and design.

Sources of interference

In general, there are three basic categories of interference:

Self-interference

Emanating from an organization's own operating environment, self-interference is a factor in both licensed and unlicensed frequencies. In either band, self-interference occurs when distinct signals come from a network under your control, whether from the same tower location or from several miles away. Furthermore, the larger and denser the network grows, the more it will be exposed to self-interference and the reliability and performance issues it may cause.

In most cases, it is best dealt with self-interference the network planning stage. In building or extending a wireless network, proper product design, ad- vanced technology (such as Cambium's industry leading use of GPS synchronization) and the ability to reuse a frequency band within the spectrum can in most cases combine to reduce self-interference to a point at which it does not have a significant impact on network performance and reliability.

External interference

In unlicensed frequencies, interference is more difficult to manage, since the interference comes from networks and technology not under your control. Because a single access point can support hundreds of subscribers or end users, interference can have a substantial impact.

Other networks aren't the only culprits; more and more network interference is coming from a wide range of consumer devices — such as surveillance cameras, Wi-Fi hotspots, and microwave ovens — that may operate in or near the same frequency. Furthermore, a network must be designed to not only deal with present interference sources, but must also be pre- pared to deal with potential future sources as the wireless environment evolves and usage of the spectrum expands.

Ambient Noise

Also called the noise floor, ambient noise is simply background noise that is always present in a frequency band. It is caused by the growing numbers of wireless devices — from garage door openers to other wireless networks — operating in the same unlicensed frequency. These all crowd the spectrum and can be a significant factor in degrading signal and bandwidth. Ambient noise levels increase as more devices and networks are deployed in the spectrum.

Neutralizing interference

GPS synchronization

Cambium leads the wireless industry in its usage of powerful GPS synchronization capabilities in all its PMP networks. This valuable capability dramatically reduces self-interference in licensed or unlicensed frequency bands. GPS synchronization allows all sites to be set to the exact same clock so network timing is very precise. As shown in the diagram, GPS satellite timing signals reach the GPS receivers in each of the network's access point radios establishing a common timing reference. This allows all the access point radios in the network — whether hundreds or thousands — to transmit at the same time and alter natively receive as all of the subscriber modules in the network transmit at the same time in turn. This helps prevent radio signals transmitted by an access point transceiver to interfere with reception of a user signal by another access point transceiver, perhaps the most onerous kind of self-interference in time-division duplex radio networks. With GPS synchronization, you can be certain your network can scale and grow elegantly to serve increasing numbers of users and applications.

EQUIPMENT KEY:

POINT-TO-MULTIPOINT
ACCESS POINT
CLUSTER & CLUSTER
MANAGEMENT MODULE

GPS ANTENNA

POINT-TO-MULTIPOINT
SUBSCRIBER MODULE

Figure 1 GPS Synchronization

The Navigation Satellite Timing and Ranging (NAVSTAR) and Global Navigation Satellite System (GLONASS) Global Positioning Systems (GPS) each use 24 satellites to relay information for precise derivation of position and time.

The cluster management module (CMM) contains a Cambium GPS Receiver. The CMM is a critical element in the operation of the system. At one AP cluster site or throughout an entire wireless system, the CMM provides a GPS timing pulse to each module, synchronizing the network transmission cycles.

The Oncore GPS Receiver tracks eight or more NAVSTAR or GLONASS satellites. The CMM uses the signal from at least four of these satellites to generate a one-second interval clock that has a rise time of 100 nsec. This clock directly synchronizes APs and which, in turn, synchronize the SMs in the network.

The Oncore GPS Receiver also provides

- the latitude and longitude of the GPS antenna (co-located with the CMM)
- the number of satellites that are being tracked
- the number of satellites that are available
- the date
- the time in Universal Coordinated Time (UCT)
- the altitude of the GPS antenna
- other information that can be used to diagnose network problems.

Configuration options for TDD synchronization

Cambium PMP systems use Time Division Duplexing (TDD) - one channel alternately transmits and receives - rather than using one channel for transmitting and a second channel for receiving. To accomplish TDD, the AP must provide sync to its SMs – it must keep them in sync. Furthermore, co-located APs must be synced together - an unsynchronized AP that transmits during the receive cycle of a co-located AP can prevent that second AP from being able to decode the signals from its SMs. In addition, across a geographical area, APs that can "hear" each other benefit from using a common sync to further reduce self-interference within the network.

For more information on each product series' synchronization configuration options, refer to the corresponding user guide, available here:

https://support.cambiumnetworks.com/files

Alternative to GPS synchronization

A link can operate without *GPS* sync, but cannot operate without sync. The alternative to GPS sync is to configure the AP in the link to generate a sync pulse to pass to the SM. Depending on the RF environment in which the link operates, this latter alternative may or may not be plausible.

For example, in Figure 2, AP4

- is not synchronized with any of the other APs.
- is transmitting nearby the other APs while they are expecting to receive SM transmissions from a maximum distance.

Figure 2 One unsynchronized AP in cluster resulting in self-interference

The result is self-interference. In this scenario, the self-interference can be avoided only by synchronizing the TDD transmit cycles of all APs that operate in the same frequency band.

An AP that is isolated by at least 5 miles (8 km) from any other equipment can generate and pass sync pulse without GPS timing and not risk that interference will result from the generated sync. In any other type of link, sync should be derived from GPS timing.

Although the embedded timing generation capability of the AP keeps a precise clock (configuration parameter Sync Source set to **Generate Sync Signal**), no trigger exists to start the clock at the same moment in each AP of a cluster. So, the individual AP can synchronize communications between itself and registered SMs, but cannot synchronize itself with other modules, except by GPS timing.

Time

Cambium's synchronization solutions

Cambium's entire Point-to-Multipoint (PMP) technology portfolio offers GPS synchronization to limit the network's own self-interference. The Cluster Management CMM provides Global Positioning System (GPS) synchronization to the Access Point (AP) and all associated Subscriber Modules (SM). Network operators have a choice of CMM solutions to select the option that works best for the environment.

Universal GPS (UGPS)

The UGPS provides network synchronization for smaller networks where a CMM may not be cost effective. The UGPS provides synchronization for one or two modules so that even remote areas at the edge of the network can operate with synchronization for improved performance. The UGPS works with all Cambium PMP radios. The UGPS has a small footprint and is easy to deploy.

Figure 3: Universal GPS (UGPS)



CMM5

The CMM5 (Cluster Management Module) is the latest generation of solutions for the distribution of TDD Sync signals and "Power-over-Ethernet (PoE)" in the field.

Figure 4: CMM5 Controller



Figure 5: CMM5 Injector



CMM4 (Rack Mount)

The cluster management module (CMM) is the heart of the Cambium system's synchronization capability, which allows network operators to reuse frequencies and add capacity while ensuring consistency in the quality of service to customers. For operators who prefer indoor CMM mounting, Cambium offers the Rack-Mounted Cluster Management Module 4. The unit is designed to be mounted onto a standard 19-inch telecommunications rack and to allow the Cambium CMM4 to be co-located with other telecommunications equipment.

Figure 6: CMM4 Rack Mount



CMM4 (Cabinet with switch)

Designed to deliver consistent and reliable wireless broadband service, the PMP system gracefully scales to support large deployments. The cluster management module is the heart of the system's synchronization capability which allows network operators to re-use frequencies and add capacity while ensuring consistency in the quality of service to customers. As a result, subscribers can experience carrier-grade service even those at the outer edge of the network.

Figure 7: Cabinet (with switch)



CMM4 (Cabinet without switch)

This CMM includes all of the functionality listed above but there is no switch included. This provides the network operator the flexibility to use the switch of their choice with the power and synchronization capabilities of the CMM4.

CMMmicro (CMM3) – Product is End of Life and no longer available for new shipments

The Cluster Management Module 3 (CMM3), also known as the CMMmicro, allows network operators to reduce the time and labor cost of system installation and maintenance in AP Clusters. This management module reduces cabling between system modules and provides reliable network synchronization. There is only one cable going from the CMM3 to each module carrying the Ethernet connection, synchronization pulse and GPS data.

Figure 8: CMMmicro (CMM3)



Chapter 2: Cambium Cluster Management Module (CMM5)

The CMM5 consists of 4 subsystems, described in the following sections:

- CMM5 Controller Module
- CMM5 Injector (29 volt and 56 volt versions)
- Power supply(s) (240/600 watt)
- uGPS

Product Overview

The CMM5 (Cluster Management Module) is the latest generation of solutions for the distribution of TDD Sync signals and "Power-over-Ethernet (PoE)" in the field. The CMM5 is a modular design with individual 4-port power injectors and an optional controller used for remote management.

Key features of the CMM5 include:

- Support for Gigabit Ethernet (1000BaseT)
- Modular and scalable from 4 ports to 32 ports
- Direct +/- 48VDC input (optional AC/DC power supplies are available from Cambium Networks)
- Uses Cambium Networks uGPS for a synchronization source
- Dual resilent power inputs
- Rack mountable
- Secure remote management when used with the optional CMM5 Controller Module
- Support for PMP 450m (cnMedusa™)
- Future support for integration into (cnMaestro™) for cloud or NOC-based management

Cluster Management: Scenario 1

The following is a CMM5 Cluster Management scenario using four PMP 450i Access Points in the simplest configuration.

Scenario/Req'ts.	Equipment Needed	Features
 Four PMP 450i Access Points 48 VDC Available No management or resiliance required 	56 Volt Injector uGPS	 Gigabit Ethernet Local Management Interface +/- 48VDC Input Broad Device Support Rack Mountable




Figure 9: Cluster Management: Scenario 1

Cluster Management: Scenario 2

The following is a CMM5 Cluster Management scenario using four PMP 450i Access Points and four PMP 450 Access Points introducing the controller, multiple injectors and resilient power supplies.

Scenario	Equipment Needed	Features
Four PMP 450i Access Points Four PMP 450 Access Points AC only environments Management required. Resilence required.	 56 Volt Injector 29 Volt Injector 1 CMM5 Controller One uGPS Two AC-to-48VDC Power Supplies 	 Gigabit Ethernet support Local Management Interface +/- 48VDC Input Broad Device Support Rack Mountable Resilent power sources Secure, Remote Management (https) Scalable to 32 devices




Figure 10: Cluster Management: Scenario 2

CMM5 Controller Module

The major features of the CMM5 Controller Module are:

- Auto-detect/control up to 8 Power Injectors
- Monitor SYNC/Power/GPS status
- Manage (up/down ports)
- Web (HTTPS) and SNMPv2/v3 management (SNMP on roadmap)
- 1U/ half-width rack-mount

Figure 11: Controller Module



CMM5 Injector Module

The CMM5 Injector Module has the following features:

- Stand-alone mode or used with controller for mgmt.
- +/- 48VDC input with green/amber LED's for status
- Injects SYNC pulse from uGPS
- 2U / half-width rack-mount

Note that there are two different versions of the injector module (56V and 29V). You must select the correct injector for the types of radios that you will be powering. In both cases, the injectors use the same input power supplies or can be powered with +/- 48VDC. The output power is different and the type of SYNC signal used is different between the two types of injectors.

Systems can have 29V and 56V injectors deployed alongside each other.

Figure 12: Injector Module



CMM5 Injector Compatibility Matrix

Table 1: Injector Compatibility Matrix

Product	Power/Injector Model	Sync
PMP/PTP 450i	Yes/56V	Yes
PMP 450m	Yes/56V	Yes
ePMP 2000	Yes/56V	Roadmap
PTP 670	Yes/56V	Roadmap

PTP 700	Yes/56V	Roadmap
PMP 450/PTP 450	Yes/29V	Yes
PMP 100/PTP 100	Yes/29V	Yes

CMM5 Specifications

The following table provides specifications for the CMM5 Power & Sync Injector (56 Volts).

Table 2: CMM5 Specifications

CMM5 Power and Sync Injector 56 Volts			
Model Number	C000000L556A		
Data Interface	4 each RJ45 Gigabit Powered output ports "To Radios"		
	4 each RJ45 Gigabit Data input ports "To Switch Array"		
	1 each GPS timing port (RJ-12)		
	1 each CMM5 USB Serial port for local administration		
	1 each RJ12 Daisy Chain port "IN"		
	1 each RJ12 Daisy Chain port "OUT"		
Surge Suppresion	Lightning Suppression for each "To Radios" RJ45 Port		
Power Input Voltage: + or - 48 VDC			
	Input Power Consumption: 400 watts		
	Output Voltage: + or - 55 VDC		
	Output Current: 0 - 1.8A per channel		
	Output Power: 0 - 90 Watts per channel		
Cabinet Temperature	-40° C to +55°C (-40° F to +131° F), 90% humidity, condensing		
Physical	Max Distance from Managed Radios: 328 cable feet (100m)		
	Max Distance to GPS Antenna: 100 cable feet (30.5m)		
Dimensions	8.85" W x 15.75" D x 1.65" H (225mm x 400mm x 42mm)		
Unit Weight	6.6 pounds (3kg)		
Power Interface Terminals	2 Power input ports for 48 VDC Power (<i>Power supplies sold separately</i>)		

240 Watt Power Supply

The CMM5 240 watt AC/DC power supply provides 56 VDC to the input on both the injector and controller modules.

Cambium Networks part number: N000000L054B



600 Watt Power Supply

The CMM5 600 watt AC/DC power supply provides 56 VDC to the input on both injector and controller. Cambium Networks part number: N000000L101A



Power Supply Selection (When to use Each One)



IMPORTANT!

The power supply or supplies for the CMM5 must be separately ordered. Alternatively, if a +/-48 VDC source is available the CMM5 can be powered directly from that DC source.

You can use Cambium power supplies or an existing +/-48 VDC supply.

Table 3: Power Supply Selection

Equipment Configuration	Power Supplies Required	Notes
1 to 4 PMP 450i APs	240 watt (48-55V)	With accessories
2 PMP 450m	240 watt (48-55V)	With accessories
4 PMP 450m	600 watt (48-55V)	With accessories
2 PMP 450m and 2 PMP 450i	600 watt (48-55V)	With accessories

Note: The Controller consumes less than four watts and can also be powered by the same supply ir configuration.

Power Line Filter

In order to meet regulatory requirements in all deployment scenarios, a power line filter module is recommended to be installed on the DC side of the power supply. This module may be ordered from Cambium Networks (part number N000000L056A).

Figure 13: DC Line Filter



Ferrite Beads

In order to meet regulatory requirements in all deployment scenarios, ferrite beads are recommended to be attached to RJ-45 Ethernet cables to suppress noise and EMI.

Part Number: 4.9mm Small Bead: Fair-Rite, 0431173951 Part Number: 6.3mm Large Bead: Fair-Rite, 0431164281

Figure 14: Ferrite Bead Composite



What's in Each Box

The following paragraphs describe the contents (product and accessories) for each ordered component of the CMM5.

Injector (56 Volt) Part Number: C000000L556A

Quantity	Description
1	Injector (56 Volt)
2	Rack Mount Ears (short)
1	Rack Mount Ear (long)
1	6 Foot (1.8 Meter) USB Cable
1	8/32 SS Screw & Nut
1	Connector Bar
8	6/32 SS Countersunk Screws
2	Phoenix Input Connector

Injector (29 Volt) Part Number: C000000L529A

Quantity	Description
1	Injector (29 Volt)
2	Rack Mount Ears (short)
1	Rack Mount Ear (long)
1	6 Foot (1.8 Meter) USB Cable
1	8/32 SS Screw & Nut
1	Connector Bar
8	6/32 SS Countersunk Screws
2	Phoenix Input Connector

Providing Sync to CMM5 via uGPS Module


The uGPS module provides sync to the CMM5. See Section 4: UGPS for additional details. CMM5 provides power to the uGPS module. You only need one uGPS for the entire chain. Cable straight-Through RJ-12 (6-pins) from SYNC-OUT (uGPS) to the uGPS port on the first Injector of the Daisy-Chain.

You can construct your own cable or purchase this cable from Cambium Networks.

This cable can be constructed with shielded CAT5 cable with the middle 6 wires connected straight through on RJ-12 6-pin modular connectors.

N000000L103A CMM5 to uGPS Shielded Cable (20 meter)	N000000L103A	CMM5 to uGPS Shielded Cable (20 meter)
---	--------------	--

Figure 15: UGPS Module



CMM5 Planning

The following paragraphs describe planning for the CMM5 module.

Injector Cabling

The following table describes Injector cables.

Table 4: Injector Cabling

Nomenclature	Function	Cable Required
PRIMARY	Primary 48VDC	Power connector
SECONDARY	Optional Secondary 48 VDC in put for backup/resilience	Power connector
TO RADIOS	To Access Points	RJ-45 connector
TO SWITCH ARRAY	To Network	RJ-45 connector
OUT	Sync signal out	RJ-12 connector
IN	Sync signal in	RJ-12 connector
UGPS	Universal GPS	RJ-12 connector
USB	Daisy Chain other Injectors	USB Female

Controller Cabling

The following table describes Controller cables.

Table 5: Controller Cabling

Nomenclature	Function	Cable Required
NETWORK	To Network	RJ-45
USB	Daisy-Chain Controllers	USB
48 – 56 VDC	DC Power Input	Power connector

CMM5 Application Scenario: Single Injector (No Controller)

In this scenario, the displayed configuration shows a single CMM5 injector with a 240 watt power supply and a switch. In the simplest case a CMM5 injector can be deployed by itself providing sync and power to four ODU's. By default, the injector has all ports enabled and sync enabled.



Figure 16: Single Injector (No Controller)

CMM5 Application Scenario: Single Injector and Controller

In this scenario, the displayed configuration shows a single CMM5 Injector with a Controller.

Figure 17: Single Injector and Controller



CMM5 Application Scenario: Dual Injectors with Controller

In this scenario, we have 8 Medusa radios (450m) with dual CMM5 Injectors.




Figure 18: Eight Medusa Radios with Dual Injectors

Please note there is only one USB cable coming from the Controller to the CMM5. That CMM5 would become the master. The sync "Out to In" 6 pin cable has RS485 communication plus 1 pulse per second sync.




Figure 19: Controller to Injector Cabling

CMM5 Injector Initial Startup

The following paragraphs describe CMM5 Injector configuration.

Injector Initial Startup

Perform the following steps to configure the injector.

Procedure 1 Configure the Injector

- 1 Connect the uGPS antenna to the uGPS port on the front of the CMM5.
- 2 Connect the power to the CMM5 Power Ports marked "Primary" and optionally for "Secondary".
- Once the unit is powered the uGPS light will flash green momentarily then yellow for approximately thirty seconds then go back to green. Once it turns green the unit is ready to supply timing to the radios.
- 4 Connect the devices to be timed and powered to the ports marked "TO RADIOS".
- Connect the CMM5 Ports to your switch or router via the ports marked "TO SWITCH ARRAY".
- 6 The CMM5 ships with all four RJ45 "To Radio" ports enabled for power and sync.
- The CMM5 ships with one long rack mount ear and 2 short rack mount ears. When installing a single CMM5 in a rack, install one long ear and one short ear on the unit. If you are flush mounting your CMM5 on a wall or in a cabinet install the two short ears rotated 90 degrees toward the bottom of the unit.

CMM5 Controller Initial Startup

The following paragraphs describe CMM5 Controller initial startup.

Controller Initial Startup

Perform the following steps to configure the injector.

Procedure 2 Initial Startup of the Controller.

- **1** Connect the power supply.
- **2** A red light on the front panel indicates the device is powered on.
- **3** The Controller boots within 15 seconds.
- 4 Log on to the Controller with the default IP address: 169.254.1.1
- 5 Default username: root, Default password: password

Note: The CMM5 Controller implements a "fallback" IP address of 169.254.1.1 This address is always available to connect to the device regardless of the configuration of the network interface in the GUI.

CMM5 Controller Configuration


The following paragraphs describe the tasks necessary to configure the CMM5.

Log In

Perform the following steps to log into the CMM5.

Procedure 3 Log In to the CMM5

- 1 Enter your Username.
- 2 Enter your Password.
- **3** Select "Login".




Note: The "Reset" function allows you to reset your password.

Reset Password

Perform the following steps to reset your password.

Procedure 4 Reset Password on CMM5


- 1 From the login screen, select Reset.
- 2 When the Password field becomes blank, enter a new password.
- 3 Select "Login".



View System Status

This screen displays the following information:

- System Information
- Memory
- Network Information



View Network -Interface Status

This screen displays the status of an existing interface:

- Uptime
- MAC address
- IPv4 address
- Rx packets
- Tx packets




You can perform the following actions from this screen:

- Connect
- Stop
- Edit
- Delete
- Add interface

Status - Firewall


The Status – Firewall screen will display current rules applied to firewall.

Note: It is not expected that any changes would be required to the firewall.



View Synchronization Status


The main Services screen will display the status of Synchronization (ON/OFF).



View Chassis Status

From the main "Services" screen, you can view the general status of a chassis.


- Chassis Name
- Chassis Serial Number
- Chassis Type
- Chassis Temperature



Identify a Chassis

From the main "Services" screen, use the Blink/Query functions to identify a chassis.

- Blink "Blink" causes the red LEDs on the ODU ports of the selected power injector
 chassis to light up for one second. This is useful if the operator wants to confirm
 which physical module corresponds to each chassis displayed on the controller GUI.
- Query This function will update the status display for the associated chassis, including the volts and watts measurements (note that these don't get updated in real time). When this button is clicked, the controller sends a command to the chassis and waits for a response before updating the display, so it will take a few seconds to execute.




Note: The "Force Discovery" function will refresh the chassis information without rebooting the system.

Note: If "Query All" is selected, then the displays for all connected chassis are updated.

View Port Status


From the main "Services" screen, view port status (ON/OFF).



View/Configure Static Routes

From the Network – Static Routes screen, you can view existing static routes (IPv4/IPv6) and add new ones.

Note: It is not expected that any changes would be required.



Configure a New IP Address

From the main "Network - Interface" screen, you can configure a new IP address.

Procedure 5 Configure a New IP Address

- 1 From the Network-Interfaces screen, select "Add new interface".
- **2** Give the interface a name.
- 3 Select the desired protocol: (DHCP, Static Address etc).
- 4 You may have to select the interface to map to (If so, use ETH0).
- **5** Select "Submit".
- 6 Enter the IP address, subnet mask, and gateway address in the appropriate field.
- **7** Select Save and Apply to save the interface configuration data.
- After a brief delay, the new interface (and new IP address) will be configured. The interface should be accessible on 169.254.1.1.




Figure 20: Add New Interface

Figure 21: Interface Name and Protocol






Figure 22: New IP Address Configured



Set Local Time/NTP Protocol

From the System screen, you can perform the following:

- Set Local Time
- Set the Time Zone
- Enable NTP Client/Server



Update Injector Firmware

Perform the following steps to update Injector firmware. Most functionality on the CMM5 will be updated via the controller firmware. There may be occasional updates required to the injectors itself. In those cases, follow the procedure below:

Note: before starting this procedure you will first need to establish communication with the injector via its USB port. For this, you should install the FTID chip drivers and then configure TeraTerm. TeraTerm must be used because the software update is delivered with a teraterm macro.

Procedure 5 Update Injector Firmware


- 1 Create a directory on the PC and copy over the firmware (*.hex) and TeraTerm macro (*.ttl) files.
- Bring up a TeraTerm terminal window and establish communication with the CMM5 serial port.
- **3** From the TeraTerm window, run the macro from the Control -> Macro menu.
- A file selection dialog box will open. Select the macro that was copied over and run it.
- Another dialog box will open, from which the firmware file to be uploaded is selected.
- The macro will automatically write the contents of the firmware to the CMM5, which boots on the new image. The previous module configuration is carried-over unchanged.
- If the upgrade fails, the CMM5 module will display an error message and will come up in the bootloader state. In this case disconnect all cables except the USB connection and rerun the macro

Update Controller Firmware

Perform the following steps to update Controller firmware:

Procedure 6 Update Controller Firmware

- **1** From the System screen, select Backup/Flash Firmware.
- 2 Select Browse and select a sysupgrade-compatible image.
- **3** Once you have selected an image, select Flash Image.
- 4 Place a check mark in the "Keep Settings" box if desired.



Installing the CMM5

Ensure that you comply with standard local or national electrical and climbing procedures when you install the CMM5.



WARNING!

Installing a CMM involves electrical power and can involve height and exposure to RF (Radio Frequency) energy. To avoid personal injury, know and follow applicable national and local safety regulations and industry best practices, and follow the specific guidelines in this document

Avoiding Hazards

Use simple precautions to protect staff and equipment. Hazards include exposure to RF waves, lightning strikes, power lines, and power surges. This section specifically recommends actions to abate these hazards.

Grounding Equipment

Effective lightning protection diverts lightning current safely to ground, Protective Earth (PE) $\frac{1}{2}$. It neither attracts nor prevents lightning strikes.

Grounding Infrastructure Equipment

To protect both your staff and your infrastructure equipment, implement lightning protection as follows:

Observe all local and national codes that apply to grounding for lightning protection.

Before you install your modules, perform the following steps:

- Engage a grounding professional if you have any questions on grounding.
- Install lightning arrestors to transport lightning strikes away from equipment. For
 example, install a lightning rod on a tower leg other than the leg to which you mount
 your module.
- Connect your lightning rod to ground.
- Plan to use an appropriate surge suppressor on any Ethernet cable at the point where it enters any building or structure.

Install your modules at least 2 feet (0.6 meters) below the tallest point on the tower, pole, or roof.

Conforming to Regulations

For all electrical purposes, ensure that your network conforms to applicable country and local codes, such as the NEC (National Electrical Code) in the U.S.A. If you are uncertain of code requirements, engage the services of a licensed electrician.

In particular, many codes require that wired electrical devices like the 54 VDC power supply either terminate in a plug connection or be wired with an on/off switch, and not be hardwired to AC/mains.

Protecting Cables and Connections

Cables that move in the wind can be damaged, impart vibrations to the connected device, or both. At installation time, prevent these problems by securing all cables with cable ties, cleats, or weather-resistant tape.

The cable can be a path for water to follow to enter the cable connector or even the module. You can prevent this problem by including and securing a drip loop where the cable enters the module enclosure.

Testing the Components

The best practice is to connect all the components - BHs, APs, uGPS antenna, and CMM5 - in a test setting and initially configure and verify them before deploying them to an installation. However, circumstances or local practice may require a different practice.

Unpacking Components

When you receive products, carefully inspect all shipping boxes for signs of damage. If you find damage, immediately notify the transportation company.

As you unpack the equipment, verify that all the components that you ordered have arrived. Save all the packing materials to use later, as you transport the equipment to and from installation sites.

Installing a uGPS Antenna

Please refer to 4-16 for instructions on installing a uGPS antenna. Note that the CMM5 Injector provides power to the uGPS.

Installing a Single Controller

Perform the following procedure to install a single CMM5 Controller:

Procedure 1 Installing the Controller

- **1** Ensure that the following hardware is available:
 - (2) standard mounting ears for a 19-inch rack
 - (2) spacers
 - (4) mounting screws for each mounting ear
- **2** Use 4 mounting screws to secure the mounting ear to the Controller.
- **3** Use 2 mounting screws to secure the other end of the mounting ear to the rack.




Figure 23 Installing a Single Controller

Installing a Single Injector

Perform the following procedure to install a single CMM5 Injector.

Note that the injector requires 2U of rackspace to account for the heat dissipation. The heat sink extends into the 2nd Unit of rackspace.




Figure 24: Single Injector Rack Space

Procedure 2 Installing a Single Injector

- 1 Ensure that the following hardware is available:
 - (2) standard mounting ears for a 19-inch rack
 - (2) spacers
 - (4) mounting screws for each mounting ear
- 2 Use 4 mounting screws to secure the mounting ear to the Injector.
- **3** Use 2 mounting screws to secure the other end of the mounting ear to the rack.



Figure 25: Installing a Single Injector

Installing Two Injectors side by side

Perform the following procedure to install two Injectors side by side in a 19" rack.

Procedure 3 Installing Two Injectors

- 1 Ensure that the following hardware is available:
 - (2) standard mounting ears for a 19-inch rack
 - (2) spacers
 - (4) mounting screws for each mounting ear
 - (1) joining bar (w/attaching hardware)
 - (1) joining screw (mounted in rear)
- 2 Use 4 mounting screws to secure a mounting ear to the left side of the injector.
- **3** Use 4 mounting screws to secure a mounting ear to the right side of the injector.
- 4 Attach the joining bar (with hardware) to the Injectors as shown.
- **5** Use 2 mounting screws to secure the other end of the mounting ear to the rack.
- 6 Install the rear joining screw as shown.



Figure 26: Two Injectors with Joining Bar



Figure 27: Rear Attaching Screw

Installing a Controller/Injector side by side

Perform the following procedure to install a Controller/Injector combination.

Procedure 4 Installing a Controller/Injector Combination

- 1 Ensure that the following hardware is available:
 - (2) standard mounting ears for a 19-inch rack
 - (2) spacers
 - (4) mounting screws for each mounting ear
 - (1) joining bar (w/attaching hardware)
 - (1) joining screw (mounted in rear)

- 2 Use 4 mounting screws to secure the mounting ear to the Injector.
- 3 Use 2 mounting screws to secure the other end of the mounting ear to the rack.
- 4 Attach the joining bar (with hardware) as shown.
- 5 Install the rear joining screw as shown.





Installing a 600 Watt Power Supply

Perform the following procedure to install a 600 Watt Power Supply.

Procedure 4 Installing Two Injectors

- 1 Ensure that the following hardware is available:
 - (2) standard mounting ears for a 19-inch rack
 - (2) spacers
 - (4) mounting screws for each mounting ear
 - (1) joining bar (w/attaching hardware)
 - (1) joining screw (mounted in rear)

2 Use 4 mounting screws to secure the mounting ear to the Injector.








Figure 30: 600 Watt Power Supply Installation (rear view)


Installing a Split DC Power Line

A split DC power line is used in situations where you have one injector and one controller.

Procedure 4 Installing a Split DC Power Line

- 1 Ensure that the following hardware is available:
 - (1) 240 Watt Power Supply
 - (1) DC Line Filter
 - (1) Junction Box
 - (1) Connector (Injector)
 - (1) Connector (Controller)
 - (2) Wire Nuts
 - (1) AC Line Adapter (purchased separately)
- 2 Connect the Red and Black leads of the 240 Watt Power Supply to the Line side of the D Line Filter.
- 3 Connect the Red and Black leads of the Load side of the DC Line Filter to junction box.
- 4 Connect the Injector and Controller leads to the other side of the junction box.

Figure 31: Installing a Split DC Power Line



Cabling the CMM5

Refer to the following table for cabling requirements for the CMM5 Injector.



Figure 32: Injector Front Panel

Table 6: Injector Front Panel Nomenclature

Nomenclature	Function	Cable Required
PRIMARY	Primary 48VDC	Power connector
SECONDARY	Optiona: Secondary 48 VDC	Power connector
TO RADIOS	To Access Points	RJ-45 connector
TO SWITCH ARRAY	To Network	RJ-45 connector
OUT	Sync signal out	RJ-12 connector
IN	Sync signal in	RJ-12 connector
UGPS	Universal GPS	RJ-12 connector
USB	Connect to Controller Or PC	USB Female

The following graphic shows a fully cabled Injector/Controller combination with Ferrite beads for EMI suppression.







Figure 34: Ferrite Beads on a USB Cable






Figure 35: Wiring the Power Connector

The following AWG values are recommended for all wiring applications for the CMM5 Controller and Injector:

- 12 AWG
- 14 AWG
- 16 AWG

Class A Emissions Requirements

The following are the major requirements for the CMM5 to meet Class A Emission requirements when fully loaded with access points.

- 240W and 600W AC Power supplies: It is recommended to use a DC line filter as described above.
- CMM5 56V Injectors: In some cases it may be necessary to install Ferrite beads on the input and output CAT5 Ethernet cables. Refer to the installation photos above for the recommended locations of these beads. Recommended device is a large snap on bead with inside dia. 6.3mm, to be used on all 8 pin RJ45 and 6 pin RJ25 within three inches of the CMM5.
- 10 large ferrite beads per injector.
- 1 large/1 small ferrite bead per Controller.

Chapter 3: Cambium Cluster Management Module (CMM4)

The CMM4 consists of 3 subsystems, described in the following sections:

- The CMM4 enclosure and controller board
- Power supply(s)
- An EtherWAN switch (contained only in 1090CKHH models mounted in the CMM4)

CMM4 and Controller Board

The Cluster Management Module 4 (CMM4) provides power, sync, and network connectivity for up to eight APs, backhauls, and Ethernet terrestrial feeds in a variety of configurations. The CMM4 provides

- Sync over Power over Ethernet and integrated surge suppression on the controller board for up to 8 APs or BHs. Both a custom 30 VDC power scheme and a custom 56 VDC power scheme are available. Neither is the same as the later IEEE Standard 802.3af, and neither is compatible with it.
- Managed switching using a hardened EtherWAN switch (1090CKHH models). The CMM4 ships with a 14-port EtherWAN switch and is also available without a switch. The CMM4 originally shipped with a 9-port EtherWAN switch.
- A weather-tight enclosure with either 4 or 7 glands/ports for Ethernet and power cables (1090 and 1091 models).
- Surge suppression on the controller board for the incoming 30V DC and 54V DC power lines and GPS coax cable.
- Auto-negotiation on the Ethernet ports. Ports will auto-negotiate to match inputs that are
 either 100Base-T or 10Base-T, and either full duplex or half duplex, when the connected device
 is set to auto-negotiate. Alternatively, these parameters are settable.
- An always-on NTP (Network Time Protocol) server that can provide date and time to any radio that can reach the CMM's management IP address.

Table 1 shows model numbers and Ethernet switch configurations.

Table 7 CMM4 model numbers and Ethernet switch configurations

CMM4 Model No.	CMM4 Extended Model No.	EtherWAN Switch			
		Total Ports	10/100 Base- TX Ports	10/100/1000 Base-TX Ports	Cable glands (ports)
1090CK	1090CKHH (current units)	14	12	2	7
	1090CKAA (earlier units)	9	8	1	4
1091HH	-	No Switch			7
1092HH (Rackmount)	-	No Switch		_	

Inside the CMM4 enclosure is a **controller board**, an **EtherWAN switch** (model 1090CKHH only), and a GPS coax surge suppressor.

The **controller board** injects power and synchronization on up to eight Ethernet ports and provides the equivalent of 600SS surge suppression on each of the eight ports. The controller board is managed using a web browser, Telnet, or SNMP, and is supported by the Prizm Element Management System (EMS). The controller board receives 30 VDC power and/or 54 VDC from external power supplies, and provides 20 VDC power for the EtherWAN switch and other auxiliary equipment. The controller board includes a GPS module, which provides sync and GPS information to the CMM, a management port, an override toggle switch, and an auxiliary sync port for connecting to another CMM.



IMPORTANT!

The controller board does not convert 30 VDC to 56 VDC or 56 VDC to 30 VDC. To power 56 VDC equipment from a CMM4 you must provide a 54 VDC power supply, and to power 30 VDC equipment from a CMM4 you must provide a 30 VDC power supply.

The hardened, managed **EtherWAN switch** (model 1090CKHHonly) provides a full array of networking features. For details on the EtherWAN switch, see page 3-24.

Figure 36 CMM4 internal view, including cable glands

8 Ethernet ports supporting Sync over Power over Ethernet and providing surge suppression

Patch cable between controller board management port and EtherWAN Switch

N-type coax connector for GPS antenna



Weatherized enclosure

EtherWAN 14-port hardened managed switch

Gigabit Ethernet ports

Patch cables between EtherWAN switch and controller board

Controller board

Cable Glands





Figure 37 Rackmount CMM4



Outside the enclosure the CMM4 requires a GPS antenna and a power supply.

The **GPS antenna** requires a good view of the sky, and should not be mounted at the highest point of the tower. For best satellite tracking results a clear vew of the southern horizon is required. It is included with the CMM4 and is also available as a replacement item using part number GPSANTPNM03D.

Figure 38 GPS Antenna



The model 1090CKHHand model 1091HH CMM4 as shipped includes:

- Weatherized enclosure containing the controller board, EtherWAN Ethernet Switch, and GPS coax surge suppressor. See page 3-7 for details on EtherWAN switch options.
- Patch cables between the controller board and the EtherWAN Ethernet Switch
- U-bolts and V-brackets for pole-mounting the CMM4
- GPS Antenna
- GPS antenna pole-mount kit
- A 1-hole cable gland insert for use on the DC power cable

The model 1092HH Rackmount CMM4 as shipped includes:

- Rackmounting accessories
- GPS Antenna and pole mount accessories

The CMM4 (all models) as shipped **does not** include:

- Any power supply. The appropriate power supply(s), 30 VDC and/or 54 VDC, must be ordered separately.
- Ethernet cables to connect the CMM4 to APs, backhauls, or terrestrial feeds
- Coax cable connecting the CMM4 to the GPS antenna

Power

The power supply or supplies, 30 VDC and/or 54 VDC, are ordered separately. See Table 2 for pictures of the 30 VDC and 54 VDC supplies and for power supply part numbers.

The 30 VDC power supply N000000L055A and the 54 VDC power supply N000000L054A are equipped with a screw terminal and come with no cables.

Table 8 Power supply part numbers

Name	Part Number	
30 VDC Power Supply (no cables or cords)	N000000L055A	HLG-240H-54C
54 VDC Power Supply (no cables or cords)	N00000L054A	54 VDC shown, 30 VDC model features same design



The 30 VDC power supply **N000000L055A** is now included with CMMmicros (Cluster Management Module micro). Previously, CMMmicros shipped with a 24-Volt DC power supply, but all 24 VDC modules and radios are compatible with a 30 Volt system. Note that a 54 VDC CMM power supply will not properly power on 24 VDC radio modules.

Ethernet Switch

The model 1090CKHH CMM4 is available with a hardened, full-featured Ethernet switch made by EtherWAN Systems mounted inside the CMM4 enclosure. The CMM4 ships with a 14-port EtherWAN switch. Earlier units shipped with a 9-port EtherWAN switch.

For details on the EtherWAN switch, including the download site for its separate manual, see page 3-24.

Currently CMM4s ship as model number 1090CKHH and include a 14-port EtherWAN switch. Twelve ports support 10/100Base-T Ethernet and two ports supports 1000Base-T (Gigabit) Ethernet. Typically, eight ports are connected to the eight ports on the controller board via eight Ethernet patch cables, one port is connected to the management port of the controller board, and the remaining ports are available for connecting to high speed backhauls, terrestrial feeds, or for local access.

Earlier CMM4s shipped as model number 1090CKHH and included a 9-port EtherWAN switch. Eight ports support 10/100Base-T Ethernet and one port supports 1000Base-T (Gigabit) Ethernet. Typically, eight ports are connected to the eight ports on the controller board via eight Ethernet patch cables, and the Gigabit Ethernet port is connected to the management port of the controller board if the port isn't needed for Gigabit Ethernet.

Regardless of CMM4 option chosen, one of the ports on the switch must be cabled to the management port of the controller board or other access to the controller must be provided. The eight Ethernet lines pass through the controller board and have power and sync injected, but do not themselves provide network access to management of the controller board.

CMM4 models 1091HH and 1092HH do not contain an EtherWAN switch, and operators may supply an external switch for Ethernet traffic management (such as switch-based VLAN, MAC-based trunking, port security, port mirroring, QoS, etc.)

Specifications

Table 9 CMM4 specifications

Specification	System Range
Max length from CMM to any radio	328 cable feet (100 meters)
Max length from CMM to GPS antenna	100 cable feet (30.5 meters)
Max length from CMM to another CMM, if GPS sync cable is used	100 cable feet (30.5 meters)
Dimensions	20.75" x 14.75" x 7.75" (52.7 cm x 37.5 cm x 19.7)
Weight	14.0 lbs. (6.4 kg)
Operation Temperature	-40°F to +131°F (-40°C to +55°C)
Humidity	100% condensing
Ethernet, GPS Sync, and GPS Coax Cables	The use of cables that conform to the operational temperature of the product as well as being UV light protected is mandatory. Shielded Ethernet cables are strongly recommended
Input Power	29 VDC or 56 VDC, max 10.6A (-40°C)

Table 10 Rackmount CMM4 specifications

Specification	System Range
Max length from CMM to any radio	328 cable feet (100 meters)
Max length from CMM to GPS antenna	100 cable feet (30.5 meters)
Max length from CMM to another CMM, if GPS sync cable is used	100 cable feet (30.5 meters)
Dimensions	19" x 9.5" x 1.75" or 1 Rack Space (48.25 cm x 24 cm x 4.5 cm)
Weight	6.8 lbs. (3 kg)
Ethernet, GPS Sync, and GPS Coax Cables	The use of cables that conform to the operational temperature of the product as well as being UV light protected is mandatory. Shielded Ethernet cables are strongly recommended
Input Power	29 VDC or 56 VDC, max 10.6A (-40°C)

Providing sync to CMM via UGPS Module

A UGPS module may also be used as a GPS synchronization source (or backup GPS synchronization source) for the CMM4 units. The UGPS provides GPS synchronization to the CMM unit via the CMM's Aux Sync port (location data is not provided by the UGPS module). This allows any access points or backhaul masters connected to the CMM to receive sync. *This configuration requires that the CMM4 be configured to "Slave" mode via the CMM GUI.* When using the UGPS as a synchronization source for a CMM4, a special sync cable must be used. This cable may be constructed from an RJ-11 cable using the pin configuration in Figure 51.

CMM Planning

The following sections discuss Ethernet cabling, power, syncing two co-located CMMs together, and engineering and ordering cables.

Typical Ethernet Cabling

Physical connectivity and cabling of the CMM4 is variable and is done per the specific requirements of a given installation. The following sections depict several variations for specific network configurations. Based on these typical layouts, operators should design connectivity and cabling that best meets their site-specific needs.



CMM4 models 1091HH and 1092HH do not contain an EtherWAN switch, and operators may supply an external switch for Ethernet traffic management (such as switch-based VLAN, MAC-based trunking, port security, port mirroring, QoS, etc.). This external switch may be cabled similar to the EtherWAN switch in the diagrams below.

Standard Ethernet Cabling Configuration

Figure 6 and Figure 7 show the CMM4's internal ports connected in a standard cabling configuration. In this configuration there are four Ethernet connections to radios and one connection to a terrestrial feed. The four Ethernet ports that are powered (indicated by a red light for 29V or a green light for 56V) were configured using the CMM4 configuration web page. The Ethernet connection to the terrestrial feed is not powered (no red or green light). An Ethernet cable connects the controller board management port to the EtherWAN switch. Four of the eight Ethernet ports to radios are shown as unpowered and unused in this configuration. Local access during local maintenance could be gained by connecting an Ethernet cable from a local computer to any of the unpowered ports or to an unused port on the EtherWAN switch.

Figure 39 CMM4 Standard Configuration





Figure 40 Rackmount CMM4 Standard Configuration





CAUTION!

Do not mis-cable in such a way as to put power on the controller board Management Port.

ANOTE

The 30 VDC CMM4 power supply is labeled as 30 VDC and typically measures 30 VDC at its output. The associated CMM4 terminal blocks are marked 29 VDC, and some associated SM power supplies are labeled 29.5 VDC. All of these components are elements of a nominal 30 VDC system, and can be considered "30 VDC" elements.

The 54 VDC CMM4 power supply is labeled as 54 VDC and typically measures 54 VDC at its output. The associated CMM4 terminal blocks are marked 56 VDC, and associated SM power supplies are labeled 56 VDC. All of these components are elements of a nominal 56 VDC system, and can be considered "56 VDC" elements.

A NOTE

When powering PMP 450i AP, ePMP 1000 Connectorized with GPS Sync, or Force 110 PTP devices with a 56 V powered CMM, a crossover cable must be used, or Cambium dongle N000045L001A may also be used (these devices require pins 8,7 +Vcc and pins 4, 5 DC return).

Configured for 1000Base-T (Gigabit) Ethernet Terrestrial Feed



IMPORTANT!

The surge suppression provided by the controller board does not efficiently pass 1000Base-T (Gigabit) Ethernet. Connections required to support Gigabit Ethernet should not pass through the controller board portion of the CMM4 and should have separate surge suppression.

Figure 8 shows typical cabling for supporting a Gigabit Ethernet feed. A Gigabit port of the EtherWAN switch is used for a terrestrial Gigabit Ethernet feed. The surge suppression on the controller board does not efficiently pass 1000Base-T (Gigabit) Ethernet, so the Gigabit Ethernet from the EtherWAN switch needs to

- · Be cabled so as not to go through the controller board
- Have surge suppression provided using a HyperLink Technologies AL-CAT6HPJW surge suppressor available from L-Com (http://www.l-com.com) or equivalent.

The AL-CAT6HPJW surge suppressor can be either mounted

- inside the CMM4 enclosure (using stick-and-rip tape like Velcro or other secure mounting), with the ground lug on the surge suppressor connected to the ground lug on the inside of the enclosure with 10 AWG (6 mm²) green ground wire.
- outside the CMM4 enclosure, with the ground lug on the surge suppressor connected to known-good ground/protective earth with 10 AWG (6 mm²) green ground wire.
- in the case where the CMM4 is located in a telecommunication hut, mounted outside the hut at the point of cable penetration, with the ground lug on the surge suppressor connected to known-good ground/protective earth with 10 AWG (6 mm²) green ground wire.

RS232 EtherWAN Switch Eight Ethernet Ports to Rad Aux Management Port GPS Override (RJ11) (RJ45) Receiver Toggle **Cluster Controller** Cable Glands Hyperlink Technologies To 30 VDC AP or BH TTO 56 VDC AP AL-CAT6HPJW Surge Supressor To Ground/Protected Earth

Figure 41 CMM4 cabled to use Gigabit Ethernet feed

Configured for Cambium PTP 400, 500, and 600 Series Ethernet Bridges

PTP 400, 500, and 600 Series Ethernet bridges can use the CMM4's EtherWAN switch for their network connectivity.

These units use a different powering scheme and must be powered using their external PIDU (Powered InDoor Unit), not the powering option of the controller board in the CMM4. The PIDU must be located between the CMM4 and the ODU (OutDoor Unit – the radio), so as not to put power on ports of the EtherWAN switch.




IMPORTANT!

The surge suppression provided by the controller board does not efficiently pass 1000BaseT (Gigabit) Ethernet. Connections required to support Gigabit Ethernet should not pass through the controller board portion of the CMM4 and should have separate surge suppression.

PTP 500 and PTP 600 Series bridges operate at greater than 100 Mbit speeds and so should not be cabled to the controller board portion of the CMM4. Surge suppression to protect the EtherWAN switch should be provided by a Hyperlink Technologies AL-CAT6HP-JW surge suppressor, cabled as shown in Figure 9. The surge suppressor should be mounted

- within 3 ft (1 m) of the CMM4 if the CMM4 is located outdoors
- on the outside of the building or communications but at the point of cable penetration if the CMM4 is located indoors.

Figure 42 CMM4 cabled to support PTP 500/600



PTP 400 Series bridges operate at less than 100 Mbit speeds and so can be cabled to one of the eight Ethernet ports on the controller board, thus taking advantage of the controller board for surge suppression. The port must be configured to be unpowered. The PTP 400 Series bridge is powered by its own externally located PIDU.



PTP 450 devices do not support synchronization over power port.

Power Planning

IMPORTANT!



The power supply or supplies for the CMM4 must be separately ordered – no power supplies are included under model numbers 1090CK, 1091, or 1092. (This differs from the CMMmicro where the power supply is included when model number 1070CK is ordered.) See Table 2 for pictures of the 30 VDC and 54 VDC supplies and for power supply part numbers.

A **30 VDC power supply** is needed for the following equipment:

- PMP 100 FSK regular and Advantage APs
- PMP 54400 OFDM APs
- PTP 100 FSK BHs
- PTP 54200 OFDM BHs
- PMP 450 Series OFDM APs
- ePMP Series

A 54 VDC power supply is needed for the following equipment:

- PMP 320 802.16e APs
- PMP 430 OFDM APs
- PMP 49400 OFDM APs
- PTP 49200 OFDM BHs
- PMP 450i OFDM APs (requires crossover cable N000045L001A for Ethernet
- connection)

NOTE:



In most cases SMs use the same voltage as their associated APs. Three exceptions to be aware of are

- PMP 320 SMs use 802.3af power supplies
- PMP 430 SMs use 30 VDC power supplies.
- PMP 450 900 MHz SMs use 30 VDC power supplies

There are four input power terminal blocks inside the CMM4. Two of them are for 29/30 VDC input, and the other two are for 56 VDC input. The two 29 VDC terminal blocks and the two 56 VDC terminal blocks allow the CMM4 to be powered from redundant power supplies, if so desired.

The 30 VDC CMM4 power supply is labeled as 30 VDC and typically measures 30 VDC at its output. The associated CMM4 terminal blocks are marked 29 VDC, and some associated SM power supplies are labeled 29.5 VDC. *All of these components are elements of a nominal 30 VDC system, and can be considered "30 VDC" elements.*

The 54 VDC CMM4 power supply is labeled as 54 VDC and typically measures 54 VDC at its output. The associated CMM4 terminal blocks are marked 56 VDC, and associated SM power supplies are labeled 56 VDC. *All of these components are elements of a nominal 56 VDC system, and can be considered "56 VDC" elements.*

One of the CMM 56 VDC blocks has 2 terminals while the other has 3. The third terminal provides an additional grounding point, if needed.

If you are using a CMM4 to power both 30 VDC and 56 VDC systems, then you must install both 30 VDC and 54 VDC power supplies along with the CMM4. These power supplies must be wired to the correct terminal blocks (marked 29 VDC and 56 VDC).

IMPORTANT!

This advisory only affects operators using a CMM4 that supplies power to both 30V devices (PMP100 radios) and 56V devices (PMP430 or PMP320 radios) via discontinued ACPS120WA power supplies. This configuration does NOT require a 1k 5W resistor on the CMM4 29V terminals (This 30V power supply was made available for order around December 3, 2010). The phased out 30V model ACPS112WA power supply will always require a 1k 5W resistor when a 56V supply is present. Since both power supplies look identical, see the label under the power supply to identify the model.



Power supply model ACPS112WA requires a 1k 5W resistor across the 30V DC input terminal of the CMM4 when both 30V AND 56V are present. Doing so will prevent the 30V power supply to not always come out of sleep mode with a light load. The power supply will attempt to come out of sleep mode, and if it does not see sufficient load it goes into a sleep/recovery cycle that is observable by watching the 30V LED on the port connector turn on and off.

Power supply Model ACPS120WA satisfies the European Union's Energy Level 5 requirement and DOES NOT require a 1k 5W resistor.

See Procedure 7 Installing a special resistor for dual-powered CMM4s for more information.

The 30 VDC and 54 VDC power supplies are rated for outdoor temperatures, but are not weather tight and so must be mounted in a communications hut or enclosure provided by the operator. They should not be mounted inside the CMM4 enclosure, as it is not designed to handle the additional heat load of the power supplies. (Although it appears there is space for the power supplies, the key constraint is the surface area of the enclosure for dissipating heat, not the volume of the enclosure.)

With most of the 30 VDC radios, the radio uses up to 10 W and the input voltage as measured at the "29 VDC" terminals on the CMM4 must be between 22 and 32 VDC to support 8 APs at the maximum 100 m (328 ft) Ethernet cable length.

With PMP 54400 APs, the radio uses up to 12 W at 30 VDC and the input voltage as measured at the "29 VDC" terminals on the CMM4 must be between 28 and 32 VDC to support 8 APs at the maximum 100 m (328 ft) Ethernet cable length.

When supporting 56 VDC systems, the input voltage as measured at the "56 VDC" terminals on the CMM4 must be between 44 and 59 VDC.

The CMM4 controller board provides two 20 VDC outputs – one for the EtherWAN switch, and one optionally available for powering another low power device mounted in the enclosure by the operator, such as a fiber-to-copper media converter. Total 20 VDC accessory power should not exceed 20 W.

In cases where -48 VDC power is available and powering from the -48 VDC is desired (for example, in some telecommunications huts), procure a -48 VDC to +56 VDC converter such as a Mean Well Model SD-350C-48 and install between the -48 VDC source and the +56 VDC power supply.



EU Countries Only

To enable regulatory compliance with the European Union (EU) directives, a power line filter module must be installed on the DC side of the power supply. This module may be ordered from Cambium Networks (part number N000000L056A). Please reference section EU countries only – power line filter module installation on page 3-55.



Syncing Two Co-located CMMs Together

Two CMMs can be synced together to meet either of the following goals:

- Case 1 One GPS antenna for two CMMs: Use a single GPS antenna to support two CMMs.
 This can be advantageous for a site with 2 CMMs where the site owner is charging per antenna and the operator wishes to minimize site costs by only installing one GPS antenna.
- Case 2 Redundant Sync: Take advantage of co-located CMMs, each with its own antenna, to
 provide "warm spare" redundant sync. If one GPS antenna, coax cable, or GPS module has
 problems, remote re-configuration can re-establish sync to that CMM.

The CMMs can be any combination of CMMs - either two CMM4s, two CMMmicros, or a CMM4 and a CMMmicro.

Syncing two CMMs together requires connecting their RJ-11 auxiliary ports together with a 6-wire cable and configuring each CMM appropriately. The location of the RJ-11 auxiliary port is shown in Figure 3.

The connection cable is a special cable, not a straight-through cable. See page 3-23 for information on the cable and Figure 11 for cable pinouts.

Case 1 – Redundant Sync

In this case, each CMM is connected to its own GPS antenna via coax in the standard way, and the two CMMs are connected via a special cable between the auxiliary sync RJ-11 ports of each CMM. If one CMM loses sync due to problems with its GPS antenna, coax cable, or GPS module, that CMM can be re-configured remotely over the network to get sync from the other CMM by going to the **Configuration** > **CMM** web page and setting the sync source to **Slave (RJ11 Port)**.

In normal operation, the appropriate web pages of each CMM will display GPS information, as will the appropriate pages of connected APs and BHMs. Each CMM can be used as a NTP (Network Timing Protocol) server for time-of-day information for APs and BHMs, configured at the AP or BHM.

Once reconfigured to get sync over the auxiliary sync RJ-11 Port, a CMM and its connected APs and BHMs will no longer display GPS information. That CMM will no longer be providing NTP server functions, and any AP or BHM configured to point to it for time-of-day will need to be reconfigured to point to a different NTP server to get accurate time-of-day information.

Depending on network design and other equipment in the network, the two CMMs may be connected with an Ethernet cable, or may be each fed separately.

Case 2 – One GPS antenna for two CMMs

A typical scenario for the use of Case 2 would be where a site or building owner is charging per antenna, the site requires 2 CMMs, and the operator wishes to minimize site costs by only installing one GPS antenna.

In this case, the GPS antenna connects to one CMM via coax cable, and the two CMMs are connected via a cable between the auxiliary sync RJ11 ports of each CMM. Sync is passed from one CMM to the other via this cable. The Sync Source on the Configuration > CMM page of the CMM connected to the GPS antenna should be set to **Master (GPS Module)**, and the Sync Source on the **Configuration** > **CMM** page of the other CMM should be set to **Slave (RJ11 Port)**.

The slave CMM and its connected APs and BHMs will not display GPS information and the slave CMM will not function as an NTP (Network Time Protocol) server.

Depending on network design and other equipment in the network, the two CMMs may be connected with an Ethernet cable, or may be each fed separately.

Cables

Ethernet Cables

The operator provides the Ethernet cables between the CMM4 and the radios it supports. They must be engineered to length and are not included with the CMM4. The cable length from the CMM4 to any radio must be under 100 m (328 ft).

Cables are available from Best-Tronics, Inc., http://best-tronics.com/. These cables can be ordered in lengths up to 328 ft (100 m) and are listed in Table 5.

Table 11 Recommended Ethernet cables

Typical Use	Best- Tronics Part #	Description
Infrastructure Ethernet cable	BT-0781S- XXX	RJ-45 to RJ-45 straight, shielded, UV-resistant Ethernet cable using outdoor STP Cat 5e cable, lower cost than plenum-rated, available only in black.
Infrastructure Ethernet cable for plenums	BT-0562S- XXX	RJ-45 to RJ-45 straight, shielded, UV-resistant, plenum-rated Ethernet cable using outdoor STP Cat 5e cable, available in beige, blue, grey, or white.



IMPORTANT!


Shielded Ethernet cable is strongly recommended for AP and BH installations.

Alternatively, equivalent cables may be procured by the operator, fabricated by the operator in a depot, or fabricated at site. The modules have auto MDX/MDIX and so either straight-through or crossover Ethernet cables may be used. Pinouts for straight-through cables are shown in Table 6 and Table 7. Figure 10 shows the location of Pin 1, relative to the lock tab on the connector.

Table 12 RJ-45 pinouts for straight-through Ethernet cable - 30 VDC

Pin 1 \rightarrow	white / orange	← Pin 1	Pin	RJ-45 Straight-thru	Pin
Pin 2 \rightarrow	orange	← Pin 2	TX+ 1 ====		— 1 RX+
Pin 3 \rightarrow	white / green	← Pin 3	TX- 2		2 RX-
Pin 4 \rightarrow	blue	← Pin 4	RX+ 3		
Pin 5 \rightarrow	white / blue	← Pin 5	-4		4 -
Pin $6 \rightarrow$	green	← Pin 6	+V return		+V return
Pin 7 \rightarrow	white / brown	← Pin 7	3 ====		 3
Pin 8 \rightarrow	brown	← Pin 8	RX- 6		6 TX-
Pins 7 and	l 8 carry power to the m	odules.	+v [7 ====		— 7 _{1 +∨}
			8		8 1

Table 13 RJ-45 pinouts for straight-through Ethernet cable - 56 VDC






Figure 43 Location of pin 1



Bulk unterminated Ethernet cable can be ordered from Best-Tronics as bulk cable:

- CA-0287S: (shielded, plenum rated)
- CA-0367S: (lower cost, shielded, non-plenum-rated)

GPS Antenna Coaxial Cable

The operator provides the GPS antenna coaxial cable between the CMM4 and the GPS antenna. It must be engineered to length and is not included with the CMM4. In most cases, the cable length from the CMM4 to the GPS antenna must be under 30 m (~100 ft).

Antenna cables can be ordered from Best-Tronics, Inc., http://best-tronics.com/. Antenna cables can be ordered in lengths up to 100 ft (30.4 m), as listed in Table 8.

Table 14 Recommended antenna cable

Best- Tronics Part #	Description

Alternatively, equivalent cables may be procured by the operator, fabricated by the operator in a depot, or fabricated at site using

- Up to 100 feet (30.4 meters) of LMR200 coaxial cable
- 2 Times Microwave N-male connectors (Times Microwave P/N TC-200-NM) or equivalent connectors

i

NOTE:

The CMM4 has a female N-type coax connector on the outside of the enclosure, whereas the CMMmicro has a female BNC-type connector inside the enclosure. Take this into account when ordering or fabricating cables, and when replacing a CMMmicro with a CMM4.

DC Cables

Cambium recommends the use of flame-retardant, moisture and sunlight-resistant cable rated to 75° C wet and bendable at -25° C for the DC cable between the power supply(s) and the CMM4. Examples of such cable include General Cable (http://www.generalcable.com), catalog number 234580 for 12 AWG cable and catalog number 236300 for 10 AWG cable, found in the Telecommunications Catalog.

Recommended wire size for the CMM4's DC cable in most systems is shown in Table 9. These wire sizes support up to 8 radios (30 VDC or 56 VDC radios) at up to 100 m (328 ft) Ethernet cable length from the CMM4.

Table 15 Wire size for CMM4 DC cable

DC Power Cord Length	Wire Gauge
Under 12 ft (12.6 m)	14 AWG (2 mm²)
12 - 90 ft (3- 25 m)	12 AWG (4 mm²)
91- 145 ft (26- 45 m)	10 AWG (6 mm²)
146- 230 ft (46- 70 m)	8 AWG (10 mm ²)

For supporting 8 PMP 54400 APs or PTP 54200 BHs (which are 12 W 30 VDC radios), reduce either the maximum DC cable length or the Ethernet cable length by half. For example, if the Ethernet cable length from CMM4 to 8 PMP 54400 APs is 50 m (164 ft) or less, the DC lengths in Table 9 can be used. If the Ethernet cable length from CMM4 to 8 PMP 54400 APs is 100 m (328 ft), then halve the lengths shown in Table 9.

CMM Sync and UGPS Sync Cable

As described in on page 3-18, two CMMs (two CMMmicros, two CMM4s, or a CMMmicro and a CMM4) can be connected together with a CMM sync cable to provide either

- The ability to have one GPS antenna support two CMMs
- "Warm spare" redundant sync

Pinouts for the CMM sync cable are shown in Figure 11. Figure 12 shows the location of Pin 1, relative to the lock tab on the connector. When using a UGPS module for providing synchronization pulses to a CMM4 unit, use the pinout configuration shown in Figure 51.




NOTE:

The CMM sync cable used to connect two CMMs for sync purposes has different pinouts than the straight-through sync cable used to connect a "remote AP" to an SM, or an AP or BHM to a CMM2.

Figure 44 CMM sync cable pinout


RJ-11, 6 pin 6 connector

RJ-11, 6 pin 6 connector



Note: Only 2 pairs are used

Figure 45 Location of pin 1



EtherWAN Switch Information

This section includes key information on the EtherWAN switch. For full details and configuration information, EtherWAN switch manuals are downloadable from http://www.etherwan.com/support-mo.php. Consult Table 10 to obtain the appropriate model number for your EtherWAN switch to use to download the correct manual.

EtherWAN switch management may be accessed in one of three ways:

- Standard web-based browser interface
- External SNMP-based network management using SNMP commands or an Element Management System such as Prizm or One Point Wireless Manager
- Administration console via the switch's RS-232 serial port using Windows Hyperterminal or equivalent

The EtherWAN switch as provided has the IP address, login ID, and password as shown in Table 10.

EtherWAN Switch CMM4 10/100 **Extended** Default IP Default 10/100/1000 Login ID **EtherWAN** Total Base-Model address password Base-TX **Ports** TX Model No. No. **Ports Ports** root (not No 2 1090CKHH 14 12 EX72129A 169.254.1.1 changeable password by user) admin 1090CKAA (not Nο (earlier 9 8 1 EX96000 192.168.1.10 changeable password versions) by user)

Table 16 EtherWAN switch details

The 14-port EtherWAN switch may be reset (rebooted) either remotely or after gaining physical access to the CMM4:

- remotely: access the CMM4 controller board web page, navigate to **Configuration** > **CMM** and click the **Reset OEM Switch** button to power cycle the switch.
- after gaining physical access to the inside of the CMM4 enclosure: press the inset Reset button on the EtherWAN switch's faceplate using a nail or similar tool.

Either process reboots the switch but *does not* reset it to factory defaults.

The 9-port EtherWAN switch may be reset (rebooted) remotely by accessing the CMM4 controller board web page, navigating to **Configuration** > **CMM** and clicking the **Reset OEM Switch** button. This button power cycles the EtherWAN switch but *does not* reset it to factory defaults.

If you lose or forget the IP address of the EtherWAN switch after configuring it to an address other than the default IP address, gain physical access to the CMM4, access the EtherWAN switch via its RS-232 serial port (which doesn't require an IP address), and proceed to view or set the IP address. Alternatively, you may wish to use Wireshark, Angry IP Scanner, or other tools to discover the missing IP address.

If after configuring a password you lose or forget it, contact Technical Support for assistance, using the contact information on page x.

Configuring a CMM4

Web pages on the CMM4 provide status information and support configuration. The eight Ethernet ports can be configured, and information is provided on GPS status, Port configuration, FPGA and software revision.

For information on configuring the EtherWAN switch, see the *EtherWAN Switch Manual*. The manual is available for download as described in on page 3-24.

Configuring IP Communications Parameters

An example of the CMM4 IP tab is displayed in Figure 13.

Figure 46 IP tab of CMM4



The IP tab allows you to set the IP communications parameters for management of the CMM4.

Table 17 IP tab attributes

Attribute	Meaning
IP Address	This is the IP address of the CMM4 controller board. The EtherWAN Switch has a separate and distinct IP address that is set using the EtherWAN Switch web or serial interface.
	The default value for this parameter is 169.254.1.1.
Subnet Mask	This is the subnet mask of the CMM4 (controller board). The EtherWAN Switch has a separate subnet mask that is set using the Ethernet Switch web or serial interface.
	The default value for this parameter is 255.255.25.0.

Attribute	Meaning
Default Gateway	This is the default gateway of the CMM4 (controller board). The EtherWAN Switch has a separate default gateway setting that is set using the Ethernet Switch web or serial interface. The default for this parameter is 169.254.0.0. Since both the controller board and the 14-port EtherWAN switch have the same default IP address, either may respond when using IP address 169.254.1.1 from your PC. You can configure first whichever unit responds first, as easily determined by the distinctive web pages of the controller board or the EtherWAN switch, or you can use Procedure 1 to more deterministically access and configure the EtherWAN switch's and controller board's IP addresses.

Procedure 7 Configuring EtherWAN switch and Controller Board IP Addresses

- 1 Connect an Ethernet cable between your PC and the EtherWAN switch.
- 2 Disconnect the patch cable between the controller board management port and the EtherWAN switch.
- Enter the EtherWAN switch's web pages using your browser and IP address 169.254.1.1 and proceed to configure the EtherWAN switch.
- Reconnect the patch cable between the controller board management port and the EtherWAN switch.
- Enter the controller board's web pages using your browser and IP address 169.254.1.1 and proceed to configure the CMM4 controller board.
- **6** Disconnect your PC from the EtherWAN switch.

Overriding Forgotten IP Addresses, Usernames, or Passwords

By using the toggle switch on the CMM4 controller board, you can temporarily override a lost or unknown IP address, username, or password as follows:

- When the toggle switch is in the "Default" position (up or towards the operator), a power
 cycle causes the CMM4 to boot with the default IP address and no username or password
 required. The CMM GUI displays a message indicating that the unit has been powered up in
 default mode.
- When the toggle switch is in the "Normal" position (down or away from the operator) a power cycle causes the CMM4 to boot with your operator-set IP address, username(s) and password(s).

To override a lost or unknown IP address or password, perform the following steps.

Procedure 8 Overriding forgotten IP addresses, usernames, or passwords

1

IMPORTANT!

When rebooted into override mode the ports on the CMM4 are temporarily unpowered. APs or BHs connected to the CMM4 will not have power, so you will temporarily lose the ability to access the CMM4 through those APs or BHs.

- 1 Gain physical access to the inside of the CMM4 enclosure.
- **2** Establish direct Ethernet connectivity to the CMM4 (not through an AP or BH).
- **3** Flip the toggle switch to the "Default" position (normally up, toward you).
- Power cycle the CMM4.

 RESULT: The module can now be accessed with the default IP address of 169.254.1.1, no username, and no password. Ports are not currently powered due to toggle switch override and are shown unpowered on the Configuration > Ports tab.
- View the current IP address or set a new IP address on the Configuration > IP tab, view users on the Account > Change Users Password tab, add users on the Account > Add User tab, or set a new password on the Account > Change Users Password tab.
- Change any other configuration values if desired. If you change ANY parameters on the **Configuration** > **Ports** tab then the displayed parameters (including any unpowered ports) will be used when rebooted with the toggle switch in the "Normal" position. Leave ALL unchanged and the previous port configuration will be used.

IMPORTANT!



If you leave the parameters on the **Configuration** > **Ports** tab unchanged, the ports will return to the state they were in before the override. Those that were powered before will be powered again. However, if you click "Save Changes" on the **Configuration** > **Ports** page before rebooting then the next boot will come up with the displayed port configuration.

- 7 Click the Save Changes button.
- 8 Flip the toggle switch to the "Normal" position (nominally down, away from you).
- **9** Click the **Reboot** button.



RECOMMENDATION:

Note or print the IP settings from the **Configuration** > **IP** tab. Ensure that you can readily associate these IP settings with the module for future use.




NOTE:

An override/default plug (an RJ-11 connector with pins 4 and 6 tied together) inserted into the auxiliary port before booting the CMM4 is equivalent to using the toggle switch and will also temporarily override a lost or unknown IP address, username, or password.

Log In

An example of the CMM4 Login page is displayed in Figure 14.





With a new CMM4 or one that has been reset to factory defaults, a user can access all web pages and tabs without using a username or password. This unsecure state should be remedied by creating users and passwords as described in on page 3-32.

After users have been added, to access the web pages other than the **Home** > **General Status** tab available to GUESTS you must use the Login page to enter a user name and password.

The left side of the web page displays the current user name as **Account** and the permissions level of that user as **Level**.



All CMM user accounts are local to the device.

User Update

An example of the CMM4 User Update tab is displayed in Figure 15...

Figure 48 Changer Users Password tab of CMM4



The Change Users Password tab provides the following options:


 Table 18 Change User Password tab attributes

Attribute	Meaning
New Password	Type the new password (up to 32 alphanumeric characters) that you want to use for management access to this CMM4.
Confirm Password	Retype what you typed into the New Password parameter. If the password differs from the password you typed into the New Password field a failure message will be displayed in the Account Status field.
Change Password	To put the new password for the user into immediate effect, click this button.
Account Status	This is a read-only field that provides information on the current activity for that screen. For instance, if changing the password was successful a message will be displayed indicating the new password is active.

Add User

An example of the CMM4 Add User tab is displayed in Figure 16.

Figure 49 Add User tab of CMM4



If you are of ADMINISTRATOR level, the Add User Tab provides the following options to you.


Table 19 Add User attributes

Attribute	Meaning
User Name	Type the user name that you want to assign to the user you are adding.
Level	Use the down arrow to select the desired permission level for the user you are adding. Choices include INSTALLER and ADMINISTRATOR with the difference being that a user with INSTALLER permissions can only change their own password and cannot add or delete users, whereas a user with ADMINISTRATOR permissions can change any user's password and can add and delete users.
New Password	Type the new password (up to 32 alphanumeric characters) for management access to this CMM4 by the user you are adding. Leaving this field blank means no password is needed and any password (or no password) will allow the user to log in.
Confirm Password	Retype what you typed into the New Password parameter. If there is a failure the "Account Status" will indicate that the new password failed.
Account Status	This is a read-only field that provides information on the current activity for that screen. For instance, if adding a new user was successful a message will be displayed indicating the user has been added.

Delete User

An example of the CMM4 Delete User tab is displayed in Figure 17.

Figure 50 Delete User tab of CMM4



If you are of ADMINISTRATOR level and want to remove a user, the Delete Users Password tab allows you to do so as follows:


Table 20 Delete User attributes

Attribute	Meaning
User	Use the down arrow to select the user you want to remove. Note that the username used to log into the radio may not be deleted
Delete	Ensure that the intended user is selected. Then click this button.
Account Status	This is a read-only field that provides information on the current activity for that screen. For instance, if deleting the user was successful a message will be displayed indicating the user has been deleted.

Configuring the CMM4 ports

An example of the CMM4 Port Configurations tab is displayed in Figure 18.

Figure 51 Port Configuration tab of CMM4



The Port Configurations tab provides the following parameters.


Table 21 Port Configuration attributes

Attribute	Meaning
Port 1 to 8: Description	This is a user-defined field that identifies the port. It appears in the Home -> General Status page.
Port 1 to 8: Power On or Off	Select Power On to restore power over Ethernet to the device that is connected to this port or Power Off to remove power from it.
Ports 1 to 8: Power Cycle	A button to invoke this feature is visible only when the port is powered up.
Ports 1 to 8: Device Type	Select 29 V or 56 V to identify the type of power supplied to that port. The red light indicates 29 V and the green light indicates 56V on the port status bar.

Configuring General CMM4 Parameters

An example of the CMM4 Configuration tab is displayed in Figure 19.

Figure 52 CMM4 Configuration tab



The CMM4 Configuration tab provides the following parameters.

Table 22 CMM tab attributes


Attribute	Meaning	
Session Timeout	Enter the expiry in seconds for remote management sessions via HTTP, telnet, or ftp access to the CMM4 up to a maximum of 2592000 seconds.	
Webpage Auto Update	Enter the frequency (in seconds) for the web browser to automatically refresh the web-based interface. The default setting is 0. The 0 setting causes the web-based interface to never be automatically refreshed.	
Ethernet Switch Power	If you change this value and then click Save Changes , the change becomes effective immediately and the previous value is lost.	
Sync Source	Specify how the CMM4 should receive timing, either	
	∘ Master (GPS Module)	
	∘ Slave (RJ11 Port)	
	For additional information on using the Slave sync source, page 3-18.	
Verify GPS Message Checksum	When enabled, the device validates GPS messaging to ensure that the radio is properly receiving data from the GPS source. If a GPS source is not calculating and sending checksum data properly, the AP will still receive synchronization pulses but not GPS data (location, data, etc.) and the Invalid Message counter will increase on the radio's Home > GPS Status page. If an AP is receiving synchronization properly from a GPS unit but is not receiving GPS data, operators may set Verify GPS Message Checksum to "Disabled" to ignore checksum failures and to allow the AP to process the GPS data.	

Attribute	Meaning			
Link Speeds	If you wish to force the CMM4 to a speed or duplex state, or to return the module to auto-negotiating speed and duplex state, change the selection for the port. The range of selections is defined below:			
	Table 23 Link Speed selections for CMM4			
	Selection	Result		
	Auto Negotiation	The CMM4 attempts to auto-negotiate speed and duplex state. (This is the default and recommended setting for most network configurations.)		
	10Base T Half Duplex	The CMM4 is forced to 10 Mbps and half duplex.		
	10Base T Full Duplex	The CMM4 is forced to 10 Mbps and full duplex.		
	100Base T Half Duplex	The CMM4 is forced to 100 Mbps and half duplex.		
	100Base T Full Duplex	The CMM4 is forced to 100 Mbps and full duplex.		
		value for a port and then click Save Changes , the fective immediately and the previous value is lost.		
IP Access Control	You can permit access to the CMM4 from any IP address (IP Access Filtering Disabled) or limit it to access from only one, two, or three IP addresses that you specify (IP Access Filtering Enabled). If you select IP Access Filtering Enabled, then you must populate at least one of the three Allowed Source IP parameters or have no access permitted from any IP address, including access and management by Prizm.			
Allowed Source IP 1 to 3	If you selected IP Access Filtering Enabled for the IP Access Control parameter, then you must populate at least one of the three Allowed Source IP parameters or have no access permitted to the CMM4 from any IP address. You may populate as many as all three.			

Configuring the SNMP parameters

An example of the CMM4 SNMP tab is displayed in Figure 20.

Figure 53 SNMP tab of CMM4





CMM supports up to SNMPv2.

The SNMP tab provides the following parameters.

Table 24 SNMP tab attributes

Attribute	Meaning	
Community String	Specify a control string that allows Prizm or a Element Management System (EMS) to access the CMM4 via SNMP. No spaces are allowed in this string. The default string is Canopy . The value is clear text and is readable by a packet monitor. You can attain additional security by configuring the Accessing Subnet and Read Permissions parameters.	
Accessing Subnet	Specify the addresses that are allowed to send SNMP requests to this CMM4. The EMS must have an address that is among these addresses (this subnet). You must enter both The network IP address in the form xxx.xxx.xxx The CIDR (Classless Interdomain Routing) prefix length in the form /xx	
	 the /16 in 198.32.0.0/16 specifies a subnet mask of 255.255.0.0 (the first 16 bits in the address range are identical among all members of the subnet). 	
	192.168.102.0/24 specifies that any device whose IP address is in the range 192.168.102.0 to 192.168.102.254 can send SNMP requests to the CMM4, presuming that the device supplies the correct Community String value.	
	The default treatment is to allow all networks access.	
Read Permissions	Select Read Only if you wish to disallow any parameter value changes by Prizm or an NMS.	
Trap Address 1 to 10	Specify the IP address (xxx.xxx.xxx.xxx) of one to ten servers (Prizm or NMS) to which trap information should be sent. Traps inform the monitoring systems that something has occurred. For example, trap information is sent • after a reboot of the module. • when Prizm or an NMS attempts to access agent information but	
	either o supplied an inappropriate community string or SNMP	
	version number. o is associated with a subnet to which access is disallowed.	
Trap Enable for Sync Status	Variable to enable/disable GPS sync/out-sync traps.	

Attribute	Meaning
Site Name	Enter a name for the physical module. What you enter here will be shown on the General Status tab in the Home page of the CMM4. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.
Site Contact	Enter contact information for the physical module. What you enter here will be shown on the General Status tab in the Home page of the CMM4. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.
Site Location	Enter site information for the physical module. What you enter here will be shown on the General Status tab in the Home page of the CMM4.

Configuring VLAN

An example of the CMM4 802.1Q VLAN tab is displayed in Figure 21.

Figure 54 VLAN tab of CMM4



The VLAN tab provides the following parameters.

Table 25 VLAN tab attributes

Attribute	Meaning
Enable VLAN Tagging	If this parameter is set to Enabled and a Management VLAN ID is set in the next parameter, then the controller board's management interface will accept only frames that are VLAN tagged with the configured tag value. All frames outgoing from the management interface will have a VLAN tag, set to the configured VLAN ID.
Management VLAN ID	If Enable VLAN Tagging is set to Enabled and this parameter is set, then the management interface will accept only frames that are VLAN tagged with the configured tag value. All frames outgoing from the management interface of the CMM4 will have a VLAN tag, set to the configured Management VLAN ID .

Attribute	Meaning
Active Configuration	This field indicates the status of the current configuration. For example, VLAN tagging enabled with "1" set as the management VLAN tag would display the following: Untagged Ingress VID: 1 Management VID: 1 Current VID Member Set: VID Number Type Age 1 Permanent 0 Note that Management VLAN "1" has special properties that allow untagged VLAN frames to communicate with the device (CMM4 or radio). If the Management VLAN ID is set to 1 the local stack of the unit will accept VLAN 1 or untagged. If the Management VLAN is set to anything but 1, it will only allow that specific VLAN tag to enter the stack; it will not accept untagged
	frames.

Configuring the Unit Settings

An example of the CMM4 Unit Settings tab is displayed in Figure 22.

Figure 55 Unit Settings Tab of CMM4



The Unit Settings tab provides the following buttons.


Table 26 Unit Settings tab attributes

Attribute	Meaning
Undo Unit-Wide Saved Changes	When you click this button, any changes that you made in any tab but did not commit by a reboot of the module are undone.
Set to Factory Defaults	When you click this button, <i>all configurable parameters on all tabs</i> are reset to the factory settings.

Viewing the ARP Table (Statistics)

The ARP table provides information on the data devices connected to the CMM4. The ARP Table maps the IP address to the MAC address. The table also shows the age of the entry in the table, the interface (in this case it will always be Ethernet "et1"), and whether the packets are "pending."

Figure 56 ARP table



This ARP table example displays information on the laptop computer attached to the CMM4 for the purpose of Internet access.


Table 27 ARP Table tab attributes

Attribute	Meaning
IP Address	This field displays the IP address of the device connected to the CMM4.
Physical Address	This field displays the machine address of the device connected to the CMM4. A physical address cannot be changed. The ARP table is used by the system to translate the logical address into a physical address.
Interface	This field displays the type of interface. In the case of the CMM4, the interface will always be an Ethernet interface.
Pending	This field indicates whether the packets are pending "Y" or "N."
Create Time/Last Time	These fields are used to "age out" the entry in the table in the case where there has been no communication for a period of time.

Viewing General Status

An example of the CMM4 General Status tab is displayed in Figure 24.

Figure 57 General status tab of CMM4



Device Information		
Device :	CMM4 0a-00-3e-e8-04-03	
Software Version :	4.1 (Build 1)	
FPGA Version :	0a1107 CMM4	
FPGA Platform :	05	
PLD Version :	1 (CMM4)	
MAC Address :	0a-00-3e-e8-04-03	
System Time :	01:14:26 01/01/2001	
System Up Time :	01:14:26	
Ethernet Status :	100Base-TX Full Duplex	

Sync Status		
SYNC Pulse Status :	No SYNC	
SYNC Pulse Source :	Master (GPS Module)	
Satellites Visible :	0	
Satellites Tracked :	0	
Antenna Connection :	Unknown	
Tracking Mode :	Reserved	
Latitude :	0° 0' 0.00" N	
Longitude :	0° 0' 0.00" E	
Height:	0 meters	

Site Information		
Site Name :	Blue CMM4	
Site Location :	No Site Location	
Site Contact :	No Site Contact	

The General Status tab provides information on the operation of the CMM4. This is the tab that opens by default when you access the GUI. The General Status tab provides the following read-only fields.

Table 28 General Status tab attributes

Attribute	Meaning
Device	This field indicates the type of module and provides its MAC address.
Software Version	This field indicates the CMM4 release and the time and date of the release. If you request technical support, provide the information from this field.
FPGA Version	This field indicates the version of the field-programmable gate array (FPGA) on the module. When you request technical support, provide the information from this field.
FPGA Platform	This field indicates the hardware platform that the field-programmable gate array (FPGA) runs on.
PLD Version	This field indicates the version of the version of the programmable logic device (PLD).
MAC Address	This field displays the MAC address (or electronic serial number) of the CMM4.
System Time	This field provides GMT (Greenwich Mean Time) and date to all connected devices, which they in turn pass to devices that register to them. Data for this field is from the GPS device.
System Up Time	This field indicates how long the module has operated since power was applied.
Ethernet Status	This field indicates the speed and duplex state of the Ethernet interface to the CMM4.
SYNC Pulse Status	This field indicates the status of synchronization as follows:
	SYNC OK indicates that the module is receiving a sync pulse.
	No SYNC indicates that the module is not receiving a sync pulse.
SYNC Pulse Source	This field indicates the source of sync as follows:
	Master (GPS Module) indicates that the module is configured to receive sync from its GPS unit.
	Slave (RJ11 Port) indicates that the module is configured to receive sync through its auxiliary port from another CMM.
Satellites Visible	This field displays the number of satellites whose signals are received by the connected GPS antenna.
Satellites Tracked	This field displays the number of satellites whose signals the CMM4 uses.
Antenna Connection	This field indicates the health of the connection between the CMM4 and the GPS antenna. For example, a value of "BAD – Under Current" indicates that there is a lack of signaling due to a bad cable or GPS module.

Attribute	Meaning
Tracking Mode	If the CMM4 receives the signals from a GPS antenna, then this field describes the degree to which the CMM4 is accurately computing position information, given the satellites that it is tracking.
Latitude	If the CMM4 receives the signal from a GPS antenna, then this field displays the latitude of the site.
Longitude	If the CMM4 receives the signal from a GPS antenna, then this field displays the longitude of the site.
Height	If the CMM4 receives the signal from a GPS antenna, then this field displays the elevation (above sea level) of the GPS antenna.
Site Name	This field indicates the name of the physical module. You can assign or change this name in the SNMP tab of the CMM4 Configuration page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.
Site Location	This field indicates site information for the physical module. You can provide or change this information in the SNMP tab of the CMM4 Configuration page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.
Site Contact	This field indicates contact information for the physical module. You can provide or change this information in the SNMP tab of the CMM4 Configuration page. This information is also set into the <i>sysName</i> SNMP MIB-II object and can be polled by an SNMP management server.

Viewing Sync Status

An example of the CMM4 Sync Status tab is displayed in Figure 25.

Figure 58 Sync Status tab of CMM4



The Sync Status tab provides information on the GPS receiver in the CMM4 and the signals that it is receiving.

Table 29 Sync Status tab attributes

Attribute	Meaning
SYNC Pulse	This field indicates the status of synchronization as follows:
Status	SYNC OK indicates that the module is receiving a sync pulse from an outside source and is receiving the pulse.
	No SYNC indicates that the module is set to <i>receive</i> a sync pulse from an outside source and is not receiving the pulse.
SYNC Pulse	This field indicates the source of sync as follows:
Source	Master (GPS Module) indicates that the module is configured to receive sync from its GPS unit.
	Slave (RJ11 Port) indicates that the module is configured to receive sync through its auxiliary port from another CMM.
Satellites Visible	This field displays the number of satellites from which the connected GPS antenna <i>receives</i> a signal.
Satellite Tracked	This field displays the number of satellites whose signals the CMM4 uses.

Attribute	Meaning
Date from GPS	This field displays the month, day, and year that the CMM4 receives.
Time from GPS	This field displays the hour, minute, and second that the CMM4 receives.
Antenna Connection	This field indicates the health of the connection between the CMM4 and the GPS antenna. For example, a value of "BAD – Under Current" indicates that there is a lack of signaling due to a bad cable or GPS module.
Tracking Mode	If the CMM4 receives the signals from a GPS antenna, then this field indicates the degree to which the CMM4 is accurately computing position information, given the satellites that it is tracking. For example 2D Fix indicates that the CMM4 has a lock on information that is sufficient to compute position.
	Bad Geometry indicates that it does not.
Latitude	If the CMM4 receives the signal from a GPS antenna, then this field displays the latitude of the site.
Longitude	If the CMM4 receives the signal from a GPS antenna, then this field displays the longitude of the site.
Height	If the CMM4 receives the signal from a GPS antenna, then this field displays the elevation (above sea level) of the GPS antenna.
Invalid Message Count	Number of messages sent from the GPS receiver for which there is no match.
Restart Count	It is incremented when the CMM4 is having difficulty communicating with the GPS module
Reinit Count	The number of times the GPS device has been completely reinitialized

Viewing the System Log

An example of the CMM4 System Log tab is displayed in Figure 26.

Figure 59 System Log tab of the CMM

```
O4:38:53 UT : Mon Jan 01 2001 : System Log Cleared
04:39:07 UT : Mon Jan 01 2001 : Reboot from Webpage.
00:00:06 UT : Mon Jan 01 2001 :
******System Startup******
System Reset Exception -- Watchdog Reset
Software Version : Cmm4 4.1 (Build 1)
FPGA Version : 0a1107 CMM4
Clear System Log
```

The System Log tab provides a record of events that have been significant to this CMM4.

Viewing the Network Interface

Figure 60 Network Interface tab of the CMM

LAN1 Network Interface		
Ethernet Interface :	100Base-TX Full Duplex	
IP Address :	10.120.216.33	
Subnet Mask :	255.255.255.0	
Default Gateway:	10.120.216.254	

The Network Interface screen allows the operator to view the LAN settings for the CMM4 device. It is a read-only screen.

Table 30 Network Interface tab attributes

Attribute	Meaning
Ethernet Interface	This field displays the Ethernet mode of the LAN port.
IP Address	This field displays the IP address that the operator has set for the CMM4 controller board. This field is set in the CMM4 Configuration tab. The Ethernet Switch has a separate IP address.
Subnet Mask	This field displays the address of the subnet mask. Subnetting allows the network to be logically divided without regard to the physical layout of the network.
Default Gateway	This field displays the address of the default gateway. A default gateway is a node on the network that serves as an access point to another network.

Viewing Layer 2 neighbors

This screen provides information on all of the layer 2 devices communicating with the CMM4 including any devices on an Ethernet connected hub that support LLDP (Link Layer Discovery Protocol).

Figure 61 Layer 2 Neighbors Log



Installing a CMM4

Ensure that you comply with standard local or national electrical and climbing procedures when you install the CMM4.



WARNING!

Installing a CMM involves electrical power and can involve height and exposure to RF (Radio Frequency) energy. To avoid personal injury, know and follow applicable national and local safety regulations and industry best practices, and follow the specific guidelines in this document

Avoiding hazards

Use simple precautions to protect staff and equipment. Hazards include exposure to RF waves, lightning strikes, power lines, and power surges. This section specifically recommends actions to abate these hazards.

Grounding Equipment

Effective lightning protection diverts lightning current safely to ground, Protective Earth (PE) \downarrow . It neither attracts nor prevents lightning strikes.

Grounding Infrastructure Equipment

To protect both your staff and your infrastructure equipment, implement lightning protection as follows:

Observe all local and national codes that apply to grounding for lightning protection.

Before you install your modules, perform the following steps:

- Engage a grounding professional if you have any questions on grounding.
- Install lightning arrestors to transport lightning strikes away from equipment. For example, install a lightning rod on a tower leg other than the leg to which you mount your module.
- Connect your lightning rod to ground.
- Plan to use an appropriate surge suppressor on any Ethernet cable at the point where it enters any building or structure.

Install your modules at least 2 feet (0.6 meters) below the tallest point on the tower, pole, or roof.

Conforming to Regulations

For all electrical purposes, ensure that your network conforms to applicable country and local codes, such as the NEC (National Electrical Code) in the U.S.A. If you are uncertain of code requirements, engage the services of a licensed electrician.

In particular, many codes require that wired electrical devices like the 54 VDC power supply either terminate in a plug connection or be wired with an on/off switch, and not be hard-wired to AC/mains.

Protecting Cables and Connections

Cables that move in the wind can be damaged, impart vibrations to the connected device, or both. At installation time, prevent these problems by securing all cables with cable ties, cleats, or weather-resistant tape.

The cable can be a path for water to follow to enter the cable connector or even the module. You can prevent this problem by including and securing a drip loop where the cable enters the module enclosure.

Testing the Components

The best practice is to connect all the components - BHs, APs, GPS antenna, and CMM4 - in a test setting and initially configure and verify them before deploying them to an installation. However, circumstances or local practice may require a different practice.

Unpacking Components

When you receive products, carefully inspect all shipping boxes for signs of damage. If you find damage, immediately notify the transportation company.

As you unpack the equipment, verify that all the components that you ordered have arrived. Save all the packing materials to use later, as you transport the equipment to and from installation sites.

Cables

Information on cable planning, ordering, and design is covered on page 3-16.

Installing a GPS Antenna

The following information describes the recommended tools and procedures to mount the GPS antenna.

Recommended Tools for GPS Antenna Mounting

The following tools may be needed for mounting the GPS antenna:

- 3/8" nut driver
- 12" adjustable wrench
- 7/16" wrench
- Needle-nose pliers

Mounting a GPS Antenna

Perform the following procedure to mount a GPS antenna.

Procedure 9 Mounting the GPS antenna

- 1 Ensure that the mounting position
 - has an unobstructed view of the sky to 20° above the horizon.
 - is not the highest object at the site. (The GPS antenna does not need to be particularly high on a site, which would give it more exposure to lightning. It just needs to have an unobstructed view of the sky.)
 - is not further than 100 feet (30.4 meters) of cable from the CMM.
- 2 Select a pole that has an outside diameter of 1.25 to 1.5 inches (3 to 4 cm) to which the GPS antenna bracket can be mounted.
- 3 Place the U-bolts (provided) around the pole as shown in Figure 28...
- 4 Slide the GPS antenna bracket onto the U-bolts.
- 5 Slide the ring washers (provided) onto the U-bolts.
- 6 Slide the lock washers (provided) onto the U-bolts.
- 7 Use the nuts (provided) to securely fasten the bracket to the U-bolts.

Figure 62 Detail of GPS antenna mounting





Cabling the GPS Antenna

Connect the GPS coax cable to the female N-connector on the GPS antenna. Information on the coax cable is covered on page 3-21. Weatherproof the connection following Weatherproofing an N-type antenna connector.

Weatherproofing an N-type antenna connector

The following procedure should be used to weatherproof the N type connectors fitted to the GPS module and outdoor CMM installation connectors. This procedure must be followed to ensure that there is no moisture ingress at the N-type port.



N type connectors should be tightened using a torque wrench, set to 15 lb in or 1.7 Nm. If a torque wrench is not available, N type connectors may be finger tightened.

To weatherproof an N type connector, proceed as follows:

Figure 63 Weatherproofing an N-type antenna connector

- 1 Ensure the connection is tight. A torque wrench should be used if available:
- Wrap the connection with a layer of 19 mm (0.75 inch) PVC tape, starting 25 mm (1 inch) below the connector body. Overlap the tape to half-width and extend the wrapping to the body of the AP. Avoid making creases or wrinkles
- 3 Smooth tape edges
- 4 Cut a 125mm (5 inches) length of rubber tape (Scotch 3M Professional Grade: D.C.J. No. 06147 or equivalent)
- **5** Expand the width of the tape by stretching it so that it will wrap completely around the connector and cable
- 6 Press the tape edges together so that there are no gaps. The tape should extend 25mm (1inch) beyond the PVC tape
- Wrap a layer of 50 mm (2 inch) PVC tape from bottom to top, starting from 25 mm (1 inch) below the edge of the self-amalgamating tape, overlapping at half width
- Repeat with a further four layers of 19 mm (0.75 inch) PVC tape, always overlapping at half width. Wrap the layers in alternate directions:

Second layer: top to bottom. Third layer: bottom to top.

Fourth layer: top to bottom. Fifth layer: bottom to top.

The bottom edge of each layer should be 25 mm (1 inch) below the previous layer.

Cabling the UGPS Module

When using the UGPS as a synchronization source for a CMM4, a special sync cable must be used. This cable may be constructed from an RJ-11 cable using the pin configuration in Figure 51. Connect this cable from one of the UGPS module's sync ports to the Aux Sync port of the CMM4 unit.

450i Series AP/BHM to UGPS cable

The 450i Series requires a special cable to connect the AP or BHM to a UGPS module. The AP/BHM to UGPS cable can be constructed from RJ12 to RJ 45 cable using the ping configuration described in Table 31.

Figure 64 AP/BHM to UGPS cable




Table 31 AP/BHM to UGPS cable pinout

Pin	450i AP/BHM RJ 45 Connector	Pin	UGPS RJ 12 Connector	Connector
1	NC	1	8 on RJ 45	RJ45 8498 FE 21 8498 F
2	NC	2	NC	
3	NC	3	5 on RJ 45	
4	4 on RJ 12	4	4 on RJ 45	
5	3 on RJ 12	5	NC	
6	NC	6	7 on RJ 45	
7	6 on RJ 12			
8	1 on RJ 12			



The AP/BHM will only power up the UGPS if it configured to do so.

Installing the power supply for the CMM4 (30 VDC or 54 VDC)



WARNING!

Although the output of the power supply is 30 VDC or 54 VDC, the power rating classifies the converter as a Class 2 electric device. For this reason, whenever you work on power in the CMM4, you must *first* disconnect the DC supply from the AC power source.

Procedure 10 Installing the CMM power supply

- Install the CMM4 power supply in a hut, wiring closet, or weatherized NEMAapproved enclosure. It is designed for extreme temperatures but it is imperative to keep moisture away from the power converter.
- Do not install the power supply within the CMM4 enclosure. The CMM4 enclosure is not large enough to provide surface area for heat dissipation without the use of forced convection fans, not to provide space for additional high-power electronics.
- For the DC side of a 54 VDC power supply, engineer the DC cable, selecting the wire gauge from Table 15. Use either UV-resistant cable or shield the cable (as in a conduit) from UV rays.
 - then connect the DC cable as shown right. Insert the +V lead into the screw terminal clamp labeled "+V" and insert the GND (ground/return) lead into the screw terminal clamp labeled "-V". To insert a lead into a screw terminal clamp, first loosen the retaining screw, insert the wire into the terminal, then tighten the retaining screw. Once the cables are secure, reinstall the clear plastic cover.



A NOTE

EU Countries Only

To enable regulatory compliance with the European Union (EU) directives, a power line filter module must be installed on the DC side of the power supply. This module may be ordered from Cambium Networks (part number N000000L056A). Please reference section EU countries only – power line filter module installation on page 3-55.

supply, first ensure that the AC line is not energized. Next, remove the clear plastic cover then connect an AC cable to the power supply using
Ground/protective earth (),
Neutral (N), and Line (L) as shown right. To insert a lead into a screw terminal clamp, first loosen the retaining screw, insert the wire into the terminal, then tighten the retaining screw. Once the cables are secure, reinstall the clear plastic cover.

Figure 66 Power supply AC connection



EU countries only – power line filter module installation

To enable regulator compliance with the European Union (EU) directives, a power line filter module must be installed on the DC side of the power supply. This module may be ordered from Cambium Networks (part number N000000L056A).

Procedure 11 Installing the power line filter (EU only)

- 1 Ensure that all equipment is disconnected from main power.
- The filter may be mounted inside the CMM4 enclosure on the upper shelf using two #6 pan-head screws, 3/8" long. (Top shelf must be removed to complete this operation). Ensure that no metal burrs are resident on the CMM circuit board after attaching the filter to the top shelf. As an alternateive, adhesive-backed industrialized Velcro (for example, 3M Scotchmate MP-3526N/27N series) may be utilized to secure the filter (not included).

Figure 67 CMM4 line filter installation (EU only)



For rackmount CMM4 installations, the filter may be installed on the top of the rackmount unit using adhesive-backed industrialized Velcro (for example, 3M Scotchmate MP-3526N/27N series).




Figure 68 Rackmount CMM line filter installation (EU only)

- 3 Using spade lugs, connect the DC cables from the CMM DC input screw terminals to the "Load" side of the filter.
 - (29V installations) The length of 14 AWG or 16 AWG cabling between the CMM and filter should be 10.5 in +/-0.5 in (27 cm +/- 1 cm).
 - (56V installations) The length of 14 AWG or 16 AWG cabling between the CMM and filter should be 11.5 in +/-0.5 in (29 cm +/- 1 cm)
- Using spade lugs, connect the DC cables from the power supply to the "Line" side of the filter. The filter has no DC polarity, ensure that polarity is maintained on the wiring going through the filter (for example, the posititive wire must be connected to the same-side terminal on the "Line" and "Load" sides of the filter. Refer to Table 15 Wire size for CMM4 DC cable on page 3-22 for wire size recommendations.
- Once the filter is secured and the wiring is connected, main power may be restored.

Discontinued power supply notice – ACPS112WA only

The following procedure is only applicable to operators using a CMM4 that supplies power to both 30V devices (PMP100 radios) and 56V devices (PMP430 or PMP320 radios). The discontinued 30V model ACPS120WA power supply does NOT require the 1k 5W resistor on the CMM4 29V terminals (This new 30V power supply was made available for order around December 3, 2010). The phased-out 30V model ACPS112WA power supply will always require a 1k 5W resistor when a 56V supply is present. Since both power supplies look identical, see the label under the power supply to identify the model.

Power supply model ACPS112WA (discontinued) requires a 1k 5W resistor across the 30V DC input terminal of the CMM4 when both 30V AND 56V are present. Doing so will prevent the 30V power supply to not always come out of sleep mode with a light load. The power supply will attempt to come out of sleep mode, and if it does not see sufficient load it goes into a sleep/recovery cycle that is observable by watching the 30V LED on the port connector turn on and off.

Power supply Model ACPS120WA (discontinued) satisfies the European Union's Energy Level 5 requirement and DOES NOT require a 1k 5W resistor.

If using both 30 VDC (discontinued model ACPS112WA only) and 56 VDC power, to ensure correct operation under all conditions a 1000 Ohm 5 W resistor must be installed across the 30 VDC +V and GND (ground/return) at the terminal block using Procedure 7. The resistor can be purchased locally or call technical support to obtain one.

The resistor prevents the model ACPS112WA 30 VDC converter (discontinued) from getting stuck in sleep mode which can occur in dual-powered CMM4s and result in 30 VDC radios getting low voltage and not booting.

If redundant 30 VDC power supplies are desired along with one or two 56 VDC power supplies, connect one power supply to each of the 29 VDC terminal blocks using the resistor in one of the 29 VDC terminal blocks.

Procedure 12 Installing a special resistor for dual-powered CMM4s (30V model ACPS112WA power supply only)

- 1 WARNING Make absolutely sure 30 VDC and 56 VDC converters are unpowered and disconnected from AC (Mains) before proceeding.
- 2 Ensure white and black 30 VDC leads have 1/2 in (1 cm) of stranded wiring exposed. Strip or cut to 1/2 inch if needed.
- Wrap the stranded wires of the 30 VDC white lead around one of the leads of the 1000 Ohm 5 W resistor.
- 4 Wrap the stranded wires of the 30 VDC black lead around the other resistor lead.

Insert the wired resistor assembly into either terminal block labeled "+29 V" as shown below ensuring that the powered lead is inserted into the correct termination.

Figure 69 Resistor when using both 56 VDC and 30 VDC power



6 Screw terminal block screws down tight. The resistor dissipates 0.9 W and will run warm at room temperature.

Temperature Range

Install the CMM4 outside only when temperatures are above -4° F (-20° C). The gland openings and the bushings and inserts in the gland openings are rated for the full -40° to $+131^{\circ}$ F (-40° to $+55^{\circ}$ C) range of the CMM4. However, for dynamic operations (loosening, tightening, and inserting), they are compliant at, and rated for, only temperatures at or above -4° F (-20° C).

Installing a CMM4 (Models 1090CKHH and 1091HH)

Prizm and Wireless Manager treat the EtherWAN Switch in a CMM4 as a generic switch. For Prizm or Wireless Manager to correctly associate each EtherWAN Switch with its CMM4

- before you install the CMM4, read and note the MAC address of both the CMM4 controller and EtherWAN switch from the physical units.
- after you discover a CMM4 and its switch, use these MAC addresses for moving the switch to the place in your Prizm or Wireless Manager network view where the CMM4 was discovered.
- always maintain a record that associates these two MAC addresses.

IMPORTANT!



When an EMS discovers an EtherWAN switch in your network, it can't tell which CMM4 the switch is associated with, nor can it tell CMM4 EtherWAN switches from any other EtherWAN switches you may have in your network. The pair of MAC addresses you record directly from the CMM4 and its EtherWAN switch are the only means for you to establish the logical connection.

Perform the following procedure to install the CMM4.

Procedure 13 Mounting the CMM4

- 1 Ensure that the mounting position
 - *is not* further than 328 feet (100 meters) from the furthest AP or BH that the CMM4 will serve.
 - is not closer than 10 feet (3 meters) to the nearest AP or BH.
 - *is not* further than 100 feet (30.5 meters) of cable from the intended mounting position of the GPS antenna.
 - allows you to fully open the door for service.
- 2 Select a support structure to which the flanges can be mounted.
- **3** If the support structure is a wall, use screws or bolts (neither is provided) to attach the flanges to the wall.

If the support structure is an irregular-shaped object, use adjustable stainless steel bands (provided) to attach the CMM4 to the object.

If the support structure is a pole that has an outside diameter of 1.25 to 3 inches (3 to 8 cm), use a toothed V-bracket (provided) to

- attach the V-bracket to the pole as shown below.
- attach the CMM4 flanges to the V-bracket.

Figure 70 CMM4 V-bracket to pole mounting





Installing a Rackmount CMM4 (Model 1092HH)

Perform the following procedure to install the Rackmount CMM4.

Procedure 14 Mounting the Rackmount CMM4

- 1 Ensure that the mounting position
 - *is not* further than 328 feet (100 meters) from the furthest AP or BH that the CMM4 will serve.
 - is not closer than 10 feet (3 meters) to the nearest AP or BH.
 - *is not* further than 100 feet (30.5 meters) of cable from the intended mounting position of the GPS antenna.
- 2 Using a T10 Torx driver, attach the mounting two included mounting brackets to the front sides of the CMM4 module

Figure 71 Attaching the rackmounting brackets



3 Select a 19" rack space in which the CMM4 may be mounted and use the (4) provided Phillips head screws to attach the front of the CMM4 to the rack

Figure 72 Rackmount CMM4 rack screws



Cabling a CMM4 (Models 1090CKHH and 1091HH)

Perform the following procedure to cable the CMM4:

Procedure 15 Cabling the CMM4


- 1 Review the diagram inside the door of the CMM4.
- 2 Note that the inserts in the gland openings have precut holes.

Route Ethernet cables through the cable gland connectors to the Ethernet ports inside the CMM4 cabinet (see the grey cables in Figure 73). Stagger the cables (see Figure 74) to make it easier to feed them through the gland.

Figure 73 Ethernet port connections



Figure 74 Staggered Ethernet cables



- 4 Connect Ethernet cables as follows (see page 3-11 for typical diagrams and planning information):
 - APs, BH10s, or BH20s (PTP 100 Series bridges), PTP 230 Series bridges: cable to
 powered ports of the controller board. The controller board provides sync, power, and
 surge suppression for these connections. If the CMM4 is mounted inside a building or
 communications hut, a Cambium 600SS surge suppressor (model number 600SSC or
 later) should be mounted outside the building or communications hut on each line at
 the point of cable penetration to prevent over-voltages and over-currents from
 entering the building and potentially damaging other electronic equipment.
 - Terrestrial feeds under 100 Mbps (10/100BaseT): cable to an unpowered port of the
 controller board. The controller board provides surge suppression for these
 connections. If the CMM4 is mounted inside a building or communications hut, a
 Cambium 600SS surge suppressor (model number 600SSC or later) should be
 mounted outside the building or communications hut on each line at the point of cable
 penetration to prevent over-voltages and over-currents from entering the building and
 potentially damaging other electronic equipment.
 - Terrestrial feeds over 100 Mbps (1000BaseT Gigabit Ethernet): cable directly to the Gigabit port of the EtherWAN switch, and mount a Cambium PTP-LPU lightning protection unit or equivalent
 - o within 3 ft (1 m) of the CMM4 if the CMM4 is located outdoors
 - o on the outside of the building or communications hut at the point of cable penetration if the CMM4 is located indoors.
 - PTP 400 Series bridges: cable to an unpowered port of the controller board. If the CMM4 is inside a building or communication hut, install the bridge's PIDU (Powered InDoor Unit) also inside the building, and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent on the outside of the building or communications hut at the point of cable penetration. If the CMM4 is mounted outside, locate the PIDU in a weather-tight enclosure within 3 ft (1 m) of the CMM4 and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent within 3 ft (1 m) of the PIDU.
 - PTP 500 and 600 Series bridges: cable directly to the Gigabit port of the EtherWAN switch. If the CMM4 is inside a building or communication hut, install the bridge's PIDU (Powered InDoor Unit) also inside the building, and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent on the outside of the building or communications hut at the point of cable penetration. If the CMM4 is mounted outside, locate the PIDU in a weather-tight enclosure within 3 ft (1 m) of the CMM4 and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent within 3 ft (1 m) of the PIDU.
- On the door label, record the MAC and IP addresses of the CMM4 and all connected equipment.
- **6** Record also the MAC address of the EtherWAN switch.

- **7** Consistent with practices in your company, note the above information to add later to the company equipment database.
- 8 Connect the coax cable from the female N-connector on the GPS antenna to the female N-connector on the outside of the CMM4.
- 9 Ensure there is an Ethernet cable between the management port on the controller board and one of the Ethernet ports on the EtherWAN switch.
- Feed the DC power cord through a cable gland. A 1-hole gland insert is provided, as the DC power cable is too thick to share a gland with other cables. The 1-hole insert is either connected to one of the patch cables or included in the parts bag.
- 11 For 29 V: Connect the white wire to +29V on either of the 29 VDC terminal blocks.
- 12 Connect the black wire to V (GND) on the same 29 VDC terminal block.
- 13 For 56V: Connect the black and white wire to +56V on either of the 56 VDC terminal blocks.
- 14 Connect the black wire to –V (GND) on the same 56 VDC terminal block.
- 15 Plug the DC power supply into an AC receptacle (AC mains).
- 16 Verify that the LEDs light.

The indicator LEDs are shown in Figure 75. Color indicates position, but not state. For example, the red Power LED, in the left most position, lights when power is applied to the unit, but does not change color at any point.

Figure 75 CMM4 LED indicators

- Power
- Default
- GPS Master
- Ethernet Switch Pwr
- Link
- Activity
- Sync OK



CAUTION!

Surge suppressors should be installed on any cables where they enter a building to reduce the possibility of overvoltages or overcurrents damaging any equipment in the building.

The following equipment, mounted outside of a communications hut or building at the point where the cables penetrate the building, is recommended:

- Cambium 600SS surge suppressors for Ethernet cables
- Cambium 200SS surge suppressors for DC cables
- A PolyPhaser DGXZ+06NFNF-A surge suppressor for the coaxial cable from the GPS antenna

Cabling a Rackmount CMM4


Perform the following procedure to cable the Rackmount CMM4:

Procedure 16 Cabling the Rackmount CMM4

- 1 Connect Ethernet cables as follows (see page 3-11 for typical diagrams and planning information):
 - APs, BH10s, or BH20s (PTP 100 Series bridges), PTP 230 Series bridges: cable to
 powered ports of the controller board. The controller board provides sync, power, and
 surge suppression for these connections. A Cambium 600SS surge suppressor (model
 number 600SSC or later) should be mounted outside the building or communications
 hut on each line at the point of cable penetration to prevent over-voltages and overcurrents from entering the building and potentially damaging other electronic
 equipment.
 - Terrestrial feeds under 100 Mbps (10/100BaseT): cable to an unpowered port of the controller board. The controller board provides surge suppression for these connections. A Cambium 600SS surge suppressor (model number 600SSC or later) should be mounted outside the building or communications hut on each line at the point of cable penetration to prevent over-voltages and over-currents from entering the building and potentially damaging other electronic equipment.
 - Terrestrial feeds over 100 Mbps (1000BaseT Gigabit Ethernet): cable directly to the Gigabit port of the external switch, and mount a Cambium PTP-LPU lightning protection unit or equivalenton the outside of the building or communications hut at the point of cable penetration if the CMM4 is located indoors.
 - PTP 400 Series bridges: cable to an unpowered port of the controller board. Install the bridge's PIDU (Powered InDoor Unit) also inside the building, and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent on the outside of the building or communications but at the point of cable penetration.
 - PTP 500 and 600 Series bridges: cable directly to the Gigabit port of the external switch. Install the bridge's PIDU (Powered InDoor Unit) also inside the building, and install a Hyperlink Technologies AL-CAT6HP-JW surge suppressor or equivalent on the outside of the building or communications but at the point of cable penetration.
- 2 Connect the coax cable from the female N-connector on the GPS antenna to the female N-connector on the outside of the CMM4.
- 3 For 29 V: Connect the white wire to +29V on either of the 29 VDC terminal blocks.
- 4 Connect the black wire to V (GND) on the same 29 VDC terminal block.
- 5 For 56V: Connect the black and white wire to +56V on either of the 56 VDC terminal blocks.
- 6 Connect the black wire to –V (GND) on the same 56 VDC terminal block.
- **7** Plug the DC power supply into an AC receptacle (AC mains).
- 8 Verify that the LEDs light.

The indicator LEDs are shown in Figure 76. Color indicates position, but not state. For example, the red Power LED, in the left most position, lights when power is applied to the unit, but does not change color at any point.

Figure 76 LED indicators - rackmount CMM4





CAUTION!

Surge suppressors should be installed on any cables where they enter a building to reduce the possibility of overvoltages or overcurrents damaging any equipment in the building.

The following equipment, mounted outside of a communications hut or building at the point where the cables penetrate the building, is recommended:

- Cambium 600SS surge suppressors for Ethernet cables
- Cambium 200SS surge suppressors for DC cables
- A PolyPhaser DGXZ+06NFNF-A surge suppressor for the coaxial cable from the GPS antenna


Power Faults

If excessive current is drawn on a port, the analog circuitry reports a PoE fault. The system then turns the port power off. The power will be restored when the fault is removed.

In this power fault detection system, each port is designed with an electronic fuse that opens the DC circuit in 26ms if the 1A maximum limit is reached. Then, every 1.7 seconds the fuse will reconnect for 26ms. If the current is less than 1A during the 26ms sampling period, then the fuse will stay connected, and the port will operate as normal.

Figure 77 shows the port status screen with a power fault on port 1.

Figure 77 CMM port status showing power fault



Chapter 4: Universal Global Positioning System Module

UGPS Product Description and Overview

The Cambium Networks Universal Global Positioning System (UGPS) is a stand-alone GPS antenna and receiver with the capability to provide a 1PPS GPS synchronization signal to Cambium Networks access points (APs), backhaul masters (BHMs), or cluster management modules (CMMs).


The UPGS features two timing ports for sending GPS timing sync. One or two access points/backhaul masters/cluster management modules may be synchronized directly by the two timing ports.

The UGPS may be used with the following Cambium Networks equipment:

- PMP 100 FSK AP
- PTP 100 FSK BH
- PMP 430 OFDM AP
- PMP 400 OFDM AP
- PTP 200 OFDM BH
- PTP 230 OFDM BH (capable of sourcing power to the UGPS via PTP 230 timing port)
- PMP 320 WiMAX AP (AP Software version e2.2 and later)
- PMP 450 OFDM AP (capable of sourcing power to the UGPS via PMP 450 timing port)
- PTP 450 OFDM BH
- CMM3 (CMM3 in Slave mode, CMM3 will receive GPS synchronization pulse, but no GPS location data)
- CMM4 (CMM4 in Slave mode, CMM4 will receive GPS synchronization pulse, but no GPS location data)
- ePMP Series
- PMP 450i OFDM AP
- PTP 450i OFDM BH

The connector interface for the UGPS is detailed in Figure 78:

Figure 78 UGPS connector interface



UGPS Power Source Configurations


The UGPS module may be powered by an external source via the UGPS External Power Port. Alternately, the UGPS may be powered by a PTP 230 backhaul master or PMP 450 Platform AP via one of the UGPS Timing Ports. When the UGPS is powered by via one of the Timing Ports, the radio provides the necessary power to enable 1 PPS synchronization timing and serial GPS location data by the UGPS (which is sent back to the radio via the associated Timing Port). If the UGPS is receiving power on the External Power Port (via 30V DC power supply or CMM port) and power on Timing Port 1 or Timing Port 2 simultaneously, the UGPS defaults to using the external power supply.

External Power Only

Shown below are examples of external only powering for PMP 100 and PMP 400/430 units. In this case the UGPS is powered via straight-through RJ-45 cable connected to a Cambium approved 30V DC power supply see Table 33 Compatible 30V Power Supplies on page 4-16. The UGPS may also receive power through the RJ-45 Power Port via a power-over-Ethernet port on a CMM4. The radios receive their GPS synchronization through a straight-through 6-pin RJ-11 cable connected to either Timing Port 1 or Timing Port 2 of the UGPS.

RJ-45 Pinout for Straight-through Ethernet Power Cable

Figure 79 Power Pinout - UGPS Ethernet Power Cable



PMP 100 PMP 100 Sync (RJ-11) **PMP 100** 600SS Power over Ethernet (RJ-45) UGPS 600SS (RJ-45) UGPS **External Power** (RJ-45) RADIO 600SS **Power Supply** UGPS 600SS **Power Supply IP Default Bypass**

Figure 80 PMP 100 AP receiving synchronization from external-powered UGPS

PMP 320 **Ground Lug Tied** to Mast PMP 320 Timing (RJ-11) PMP 320 **UGPS** Power over Ethernet (RJ-45) UGPS External Power (RJ-45) RADIO 600SS **Power Supply UGPS** 600SS **Power Supply IP Default Bypass**

Figure 81 PMP 320 receiving synchronization from external-powered UGPS

Ground Lug Tied to Mast PMP 100 PMP 400/430 **PMP 100** PMP 400/430 Power over Ethernet Power over Ethernet (RJ-45) (RJ-45) 600SS 600SS PMP 400/430 Timing UGPS (RJ-11) PMP 100 Timing (RJ-11) **UGPS External Power** (RJ-45) RADIO 600SS **Power Supply** RADIO 600SS **Power Supply UGPS** 600SS **Power Supply IP Default Bypass**

Figure 82 One PMP 400/430 AP and one PMP 100 AP receiving synchronization from external-powered UGPS

Power from the Radio via UGPS Timing Port 1 or UGPS Timing Port 2

Shown below is an example of a UGPS unit powered from a PTP 230 BHM through an RJ-11 cable connected to either Timing Port 1 or Timing Port 2 of the UGPS. The UGPS may be powered by either Timing Port, and up to two radios may receive synchronization over the Timing Ports when the UGPS is powered in this fashion.




This UGPS powering mode is currently supported only by PTP 230 BHM and PMP 450 Platform AP. Future Cambium Networks hardware releases will also support providing power to the UGPS.

When powering the UGPS via AP or BHM, the system uses a straight-through 6-pin RJ-11 cable to provide power to the UGPS and to retrieve GPS synchronization pulses and data from the UGPS. The following diagram shows the wiring of the cable for sync and power.

RJ-11 Pinout for Straight-through Sync / Power Cable

Figure 83 Power Pinout - UGPS to AP/BHM Timing Port (6-pin RJ-11)



450i Series AP/BHM to UGPS cable

The 450i Series requires a special cable to connect the AP or BHM to a UGPS module. The AP/BHM to UGPS cable can be constructed from RJ12 to RJ 45 cable using the ping configuration described in Table 31.

Figure 84 AP/BHM to UGPS cable




Table 32 AP/BHM to UGPS cable pinout

Pin	450i AP/BHM RJ 45 Connector	Pin	UGPS RJ 12 Connector	Connector
1	NC	1	8 on RJ 45	RJ45
2	NC	2	NC	1234567
3	NC	3	5 on RJ 45	
4	4 on RJ 12	4	4 on RJ 45	153456
5	3 on RJ 12	5	NC	RJ12
6	NC	6	7 on RJ 45	
7	6 on RJ 12			
8	1 on RJ 12			



The AP/BHM will only power up the UGPS if it configured to do so.

PTP 230 PTP 230 Power over Ethernet (RJ-45) PTP 230 Timing and UGPS Power 600SS Cable Length < 130 ft. (RJ-11) **UGPS** 600SS (RJ-45) RADIO 600SS **Power Supply UGPS** 600SS **IP Default Bypass**

Figure 85 PTP 230 backhaul master powering UGPS and receiving synchronization


PMP 450 PMP 450 Power Over Ethernet (RJ-45) 600SS PMP 450 Timing And UGPS Power - Cable Length < 130 Ft. (RJ-11) **UGPS** 000 600SS (RJ-45) RADIO 600SS **Power Supply IP Default Bypass** IP Default Bypass Note: 450 only, 450i excluded

Figure 86 PMP 450 AP powering UGPS and receiving synchronization

PTP 230 PTP 230 PTP 230 PTP 230 Power over Ethernet Power over Ethernet (RJ-45) (RJ-45) 600SS · 600SS PTP 230 Timing and UGPS Power PTP 230 Timing and UGPS Power Cable Length < 130 ft. Cable Length < 130 ft. (RJ-11) (RJ-11) 600SS UGPS -(RJ-45) 600SS IP Default Bypass (RJ-45) RADIO 600SS **Power Supply** RADIO 600SS **Power Supply IP Default Bypass**

Figure 87 Two PTP 230 backhaul master units powering UGPS and receiving synchronization

Figure 88 PTP 230 backhaul master powering UGPS/receiving synchronization and PMP 100/430 receiving synchronization



UGPS and **CMM** Configurations

The UGPS may be used as a GPS synchronization source for Cambium Networks CMM3 and CMM4 (Cluster Management Module) units. The UGPS provides GPS synchronization to the CMM unit via the CMM's sync port. This allows any access points or backhaul masters connected to the CMM to receive sync. This configuration requires that the CMM3 or CMM4 be configured to "Slave" mode via the CMM GUI. When using the UGPS as a synchronization source for a CMM3 or CMM4, a special sync cable must be used. This cable may be constructed from an RJ-11 cable using the pin configuration in Figure 11.

When using a CMM unit, the UGPS may also be used as a redundant sync source for the CMM. If a CMM encounters an issue with the primary, coaxial-connected GPS receiver an operator may remotely login to the CMM and set the synchronization source to "Slave" to begin receiving sync from the UGPS (connected via RJ-11 cable with the pin configuration in section UGPS installation and operation).



PMP 320 Systems - When using both the UGPS for timing and a CMM4 for timing in a PMP 320 network (same AP site or an adjacent AP site), timing discrepancies between the UGPS and CMM4 can cause interference between the sites. To address this issue, operators may opt to use one type of timing in the network (either UGPS *or* CMM4). Alternatively, operators may contact technical support to set up remote access to troubleshoot the AP units that are exhibiting the issue. A future PMP 320 software release will address this timing issue.

Product Specifications

Antenna

Frequency Band L1 (1575.42 ±10 MHz)

Polarization...... Patch

Receiver

Tracking Channels 12 (Min.) Continuous Tracking

Update Rate...... 1 Hz (NMEA) Timing Accuracy (1PPS)...... 100ns RMS

Data Interface

Communications Standard......NMEA-0183

Interface Technology...... 1PPS (8Vp-p Level-Shifted Pulse, 100ms Duty Cycle)

TX GPS LOCATION DATA (8Vp-p Level-

Shifted - Serial 8/N/1 9600bps)

Acquisition

Sensitivity

Acquisition -- 148dBm
Tracking -- 165dBm

Electrical

Voltage...... 4.3V - 6V DC (Timing Ports 1 & 2: +Vap)

10V - 30V DC (External Power Port: +Vext)

500mW (2 APs Loaded; Vap=0V DC;

Vext=30V DC)

100m. (330 ft.) 2 APs Loaded; Vap=0V;

Vext=30V DC

Environmental

Operating Temperature.....-40C to +85C

Mechanical

Dimensions 6 inch(Length) x 3.5 inch(Width) x 4 inch(Dome

Height)

Shielded

Connector IP67 Rated Connector (Lapp Cord Grip Style)

Weight...... 15 Oz.

UGPS installation and operation

Observe the following guidelines when installing a UGPS module:

- The unit may be pole mounted or surface mounted (on a horizontal surface with an unobstructed view of the sky).
- The UGPS should NOT be installed as the highest object at the site.
- Orient the GPS antenna so that it has clear access to the southern horizon (if installed north of the equator) or clear access to the northern horizon (if installed south of the equator).
- Note locations of 600SS surge suppressors when installing the UGPS unit. Reference UGPS
 Power Source Configurations diagrams. Compatible power supplies for the UGPS are listed in
 Table 25.
- Observe cable length specifications in Table 26.
- Cambium Networks recommends using shielded Category 5E cables for outdoor installations.
- The UGPS Power over Ethernet pinout (External Power Port) differs from IEEE Standard 803.3af, and the two should not be intermixed. The UGPS Power over Ethernet pinout is the same as Cambium Networks FSK broadband radios.

Table 33 Compatible 30V Power Supplies and Cords

Model	Description		
N000900L001A	Gigabit Ethernet-Capable Power Supply		
N000900L007A	Cable, UL PSU Cord Set, US		
N000900L008A	Cable, UL PSU Cord Set, EU		
N000900L009A	Cable, UL PSU Cord Set, UK		
N000900L010A	Cable, UL PSU Cord Set, Brazil		

Table 34 Cable Length Specification


Configuration	Powering Method	Maximum Cable Length (feet)
External power source, up to two access points/backhaul masters	30V DC AC/DC Adapter (see Table 25) via UGPS Ext. Power Port	330
Access point/backhaul master power source, up to two access points/backhaul masters	Access Point/Backhaul master RJ-11 GPS power via UGPS Timing Port	130
▲ NOTE		
This UGPS powering mode is		
supported only by PMP 450 Platform		
AP and PTP 230 BHM . Future		
Cambium Networks hardware		
releases will also support providing		
power to the UGPS.		

A NOTE

When using the UGPS as a synchronization source for a CMM3 or CMM4, a special sync cable must be used. This cable may be constructed from the an RJ-11 cable using the pin configuration below.

Figure 89 UGPS to CMM cable pin configuration

RJ-11, 6 pin 6 connector RJ-11, 6 pin 6 connector



Note: Only 2 pairs are used

Figure 90 Location of pin 1

Clock tab is on other side)

UGPS Installation Procedure

Use the following procedure to install the UGPS module and to verify operation.

Procedure 17 UGPS installation – external-powered


- Pole mount or surface mount the GPS antenna following the installation guidelines and specifications listed in this chapter.
- For PMP 100/400/430/450 and PTP 100/200 series, configure (via web management interface) the access points/backhaul masters to sync to received GPS signal (via the timing port). Navigate to Configuration > General and set the Sync Input to Sync to Received Signal (Timing Port/UGPS). Since the UGPS will be configured with an external power source, set the UGPS Power value to Disabled.

Figure 91 Configuring the sync input and disabling UGPS power - PMP 100/400/430 and PTP 100/200 series



For PMP 320 series, configure (via web management interface) the access point to sync to received GPS signal (via the AP's RJ-11 port). Navigate to Configuration > Settings and set the Sync Source to UGPS and Serial Type to uGPS.

Figure 92 Configuring the sync source - PMP 320 series




- For PMP 100/400/430/450 and PTP 100/200 series, click **Save Changes** and reboot the radio.
 - For PMP 320 series, click **Update**, click the **Save** icon and reboot the radio.
- If connecting the UGPS to a CMM3 or CMM4, configure the CMM (via the CMM web management interface) to Slave mode (access points/backhaul masters connected to the CMM will need to be set to receive GPS sync signal from the power port). Navigate to Configuration > CMM and set Sync Source to Slave (RJ11 Port). A reboot on the CMM is required for these changes to take effect.
- Connect an RJ-11 6 pin cable from Timing Port 1 of the UGPS to the RJ-11 utility port of the access point/backhaul master to receive GPS sync signal. If applicable, repeat this step for additional access points and backhaul masters. If the UGPS is to send sync to a CMM, use a special sync cable constructed per section UGPS installation and operation.
- Install a 600SS surge supressor between the power supply and the UGPS module. Reference the diagrams in section UGPS Power Source Configurations.
- **7** Connect an RJ-45 8 pin Ethernet cable from the UGPS power port to the 600SS surge supressor.
- 8 Connect an RJ-45 8 pin Ethernet cable from the 600SS surge supressor to the power supply.
- Yerify on the access point/backhaul master/CMM that the GPS synchronization signal is being received properly. Reference section GPS Status and Location Data Readout.

Procedure 18 UGPS Installation – Powered by AP/BH Timing Port (PMP 450/PTP 230 Only)

Pole mount or surface mount the GPS antenna following the installation guidelines and specifications listed in this chapter.

Configure (via the web management interface) the access point / backhaul master to sync to received signal (timing port). Navigate to Configuration > General and set the Sync Input to Sync to Received Signal (Timing Port/UGPS). Since the UGPS will be configured to receive power over the UGPS Timing Ports, set the UGPS Power value to Enabled to configure the radio to power the UGPS.

Figure 93 Configuring the sync input and enabling UGPS power - PTP 230 series



- 3 Click Save Changes and reboot the radio.
- Connect an RJ-11 6 pin cable from Timing Port 1 or 2 of the UGPS to the timing port of the access point/backhaul master providing power and receiving sync.



This UGPS powering mode is currently supported only by PMP 450 AP and PTP 230 BHM . Future Cambium Networks hardware releases will also support providing power to the UGPS.

Verify on the access point/backhaul master that the GPS synchronization signal is being received properly. Reference section GPS status and location data readout.

Procedure 19 UGPS installation – powered by CMM PoE port

- Pole mount or surface mount the GPS antenna following the installation guidelines and specifications listed in this chapter.
- Verify that the CMM is powered by a 30V Cambium Networks power supply. This ensures that the CMM can provide the proper power-over-Ethernet output via CMM ports.

- Connect an RJ-45 8 pin Ethernet cable from the External Power Port of the UGPS to an Ethernet port on the CMM4.
- On the CMM4 web management GUI navigate to Configuration > Ports. In this configuration the CMM4 port connected to the UGPS via RJ-45 cable must be configured with Power On and Device Type Canopy 29V as Port 1 in Figure 94.



The CMM Ethernet port will only provide 29V power to the UGPS if the CMM is powered by a 29V power supply. If the CMM is powered by a 56V power supply, it will not provide 29V power via the PoE ports.




Figure 94 CMM port conifguration for UGPS power

IP default bypass

Since the UGPS is connected to the access point/backhaul master timing port, the UGPS module provides a bypass to perform an IP Default to a device connected on UGPS Timing Port 1 or 2. To perform an IP Default for a radio connected to the UGPS follow the procedures below (*not applicable to 450i Series*):

Procedure 20 IP default procedure – UGPS receiving external power

- 1 Using the power supply providing UGPS power, plug an Ethernet cable into the power adapter's "Gigabit Data" port then pin out the opposite end of the cable
- 2 Jumper the loose-end RJ-45 pins per the wiring table below:

Table 35 UGPS IP default bypass wiring

AP to Default	Wiring on External Power Connector
UGPS Timing Port 1	Connect Pins 3 and 6
UGPS Timing Port 2	Connect Pins 1 and 2

For PMP 100/400/430/450 and PTP 100/200/230/450 series, reboot the radio to be defaulted while the RJ-45 pins are jumpered. After the radio has finished rebooting, the software will be restored to a factory default configuration. For PMP 320 series, once the RJ-45 pins are jumpered while the radio is powered up, the pin contacts may then be separated and the radio may be rebooted. When the radio powers back up, the software will be restored to a factory default configuration.

Procedure 21 IP Default Proceudre – UGPS receiving power from backhaul master timing port


- 1 With the UGPS unit powered by the backhaul master's timing ports, connect an RJ-45 8 pin Ethernet cable to the External Power Port on the UGPS and pin out the loose end of the cable.
- 2 Jumper the RJ-45 pins per the wiring table below:

Table 36 UGPS IP default bypass wiring

AP to Default	Wiring on External Power Connector
Timing Port 1	Connect Pins 3 and 6
Timing Port 2	Connect Pins 1 and 2

Reboot the radio to be defaulted while the RJ-45 pins are jumpered. After the radio has finished rebooting, the software will be restored to a factory default configuration.





TIMING
PORT 1
RJ11-6

EXT. POWER
and AP IP
DEFAULT IP
BYPASS
PORT
RJ45

Figure 96 IP default bypass - default radio on timing port 2

GPS status and location data readout

The UGPS provides location data to connected synchronized devices and may be retrieved by the access point/backhaul/cluster management module web GUI or by SNMP. GPS status and location data readout is currently available on PMP 100/320/400/430, and PTP 100/200/230, series radios.

Retrieving GPS Status and Location Data via Radio Web Management GUI

Procedure 22 Retrieving GPS status and location data via radio web management GUI – PMP 100/400/430 and PTP 100/200/230 Series

- 1 With the UGPS powered and connected to the radio, navigate to **Home** > **GPS**Status.
- **2** GPS Location Data is displayed in section **GPS Status**.


Figure 97 GPS status and location data - PMP 430 example



Procedure 23 Retrieving GPS status and location data via radio web management GUI – PMP 320

- 1 With the UGPS powered and connected to the radio, navigate to **Configuration** > **General** > **Properties**.
- **2** GPS Location Data is displayed as below:

Figure 98 GPS status and location data - PMP 320



Retrieving GPS status and location data via SNMP

To retrieve GPS Status and Location Data via SNMP (Simple Network Management Protocol) from synchronized devices operators may use the following procedures.

Procedure 24 Retrieving GPS Status and Location Data via SNMP – PMP 100/400/430 and PTP 100/200/230 Series

- 1 With the UGPS powered and connected to the radio, on the radio web management GUI navigate to **Configuration** > **SNMP**.
- 2 Verify that the **Community String** and **Accessing Subnet** values are set as desired.

3 Perform a "snmpget" command for the OID desired based on Table 29.

Table 37 GPS SNMP OIDs - PMP 100/400/430 and PTP 100/200/230 series

Object Name, OID	Description		
whispGPSStatus, .1.3.6.1.4.1.161.19.3.1.3.1	GPS synchronization info (1: GPS Synchronized, 2: GPS Lost Sync, 3: Generating Sync)		
gpsSyncSource, .1.3.6.1.4.1.161.19.3.1.3.2	Source of GPS sync pulse		
gpsSyncStatus, .1.3.6.1.4.1.161.19.3.1.3.3	Current GPS sync status		
gpsTrackingMode, .1.3.6.1.4.1.161.19.3.1.3.4	GPS tracking mode		
gpsTime, .1.3.6.1.4.1.161.19.3.1.3.5	GPS time		
gpsDate, .1.3.6.1.4.1.161.19.3.1.3.6	GPS date		
gpsSatellitesTracked, .1.3.6.1.4.1.161.19.3.1.3.7	Current number of satellites GPS is tracking		
gpsSatellitesVisible, .1.3.6.1.4.1.161.19.3.1.3.8	Number of satellites visible to the GPS		
gpsHeight, .1.3.6.1.4.1.161.19.3.1.3.9	GPS height		
gpsLatitude, .1.3.6.1.4.1.161.19.3.1.3.11	GPS latitude		
gpsLongitude, .1.3.6.1.4.1.161.19.3.1.3.12	GPS Longitude		

Procedure 25 Retrieving GPS status and location data via SNMP – PMP 320

- With the UGPS powered and connected to the radio, on the radio web management GUI navigate to **Administration** > **User Management** and verify SNMP user data.
- 2 Perform a "snmpget" command for the OID desired based on Table 30

Table 38 GPS SNMP OIDs - PMP 320 series

Object Name, OID	Description		
danSyncStatus, .1.3.6.1.4.1.32584.1.1.3.2	Source of GPS sync pulse (0: No sync, 1: Sync present, 2: External sync missing – operating on internal clock, 3: Transition state - about to lose sync)		
danLatitude, .1.3.6.1.4.1.32584.1.1.1.5	System installation Latitude, Range -90 to 90		
danLongitude, .1.3.6.1.4.1.32584.1.1.1.6	System installation Longitude, Range - 180 to 180		

UGPS Power Port and Timing Port Pinouts

See Table 31 and Table 32 below for UGPS pinout information.

Table 39 UGPS Power Port Pinout

Pin	Function
1	Ground (for IP Default jumper to Pin 2)
2	Timing Port 2 AP IP Default Pin
3	Ground (For IP Default jumper to Pin 6)
4	Ground (+Vaux Return)
5	Ground (+Vaux Return)
6	Timing Port 1 AP IP Default Pin
7	+Vaux (10V-30V DC)
8	+Vaux (10V-30V DC)

Table 40 UGPS Timing Port Pinout

Pin	Function
1	1 PPS Sync Pulse (8Vo-p)
2	N/A
3	GPS Location Data – Serial 9600 bps (8Vo-p)
4	V+ (4V DC – 6V DC)
5	N/A
6	Ground (V+ Return)

Chapter 5: CMM Regulatory and Legal Notices

Important Note on Modifications

Intentional or unintentional changes or modifications to the equipment must not be made unless under the express consent of the party responsible for compliance. Any such modifications could void the user's authority to operate the equipment and will void the manufacturer's warranty.

National and Regional Regulatory Notices

U.S. Federal Communication Commission (FCC) Notification

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the US FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to correct the interference by one or more of the following measures:

- Increase the separation between the affected equipment and the unit;
- Connect the affected equipment to a power outlet on a different circuit from that which the receiver is connected to;
- Consult the dealer and/or experienced radio/TV technician for help.

Equipment Disposal



Waste (Disposal) of Electronic and Electric Equipment

Please do not dispose of Electronic and Electric Equipment or Electronic and Electric Accessories with your household waste. In some countries or regions, collection systems have been set up to handle waste of electrical and electronic equipment. In European Union countries, please contact your local equipment supplier representative or service center for information about the waste collection system in your country.

EU Declaration of Conformity for RoHS Compliance

Cambium hereby, declares that these Cambium products are in compliance with the essential requirements and other relevant provisions of Directive 2002/95/EC, Restriction of the use of certain Hazardous Substances (RoHS) in electrical and electronic equipment.

The relevant Declaration of Conformity can be found at http://www.cambiumnetworks.com/doc.php

Labeling and Disclosure Table for China

The People's Republic of China requires that Cambium's products comply with China Management Methods (CMM) environmental regulations. (China Management Methods refers to the regulation *Management Methods for Controlling Pollution by Electronic Information Products.*) Two items are used to demonstrate compliance; the label and the disclosure table.

The label is placed in a customer visible position on the product.

- Logo 1 means that the product contains no substances in excess of the maximum concentration value for materials identified in the China Management Methods regulation.
- Logo 2 means that the product may contain substances in excess of the maximum concentration value for materials identified in the China Management Methods regulation, and has an Environmental Friendly Use Period (EFUP) in years, fifty years in the example shown.

Logo 1



Logo 2



The Environmental Friendly Use Period (EFUP) is the period (in years) during which the Toxic and Hazardous Substances (T&HS) contained in the Electronic Information Product (EIP) will not leak or mutate causing environmental pollution or bodily injury from the use of the EIP. The EFUP indicated by the Logo 2 label applies to a product and all its parts. Certain field-replaceable parts, such as battery modules, can have a different EFUP and are marked separately.

Table 41 Disclosure Table for China

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价 铬 (Cr ⁶⁺)	多溴 联苯 (PBB)	多溴二苯醚 (PBDE)
金属部件	×	0	×	×	0	0
电 路模 块	×	0	×	×	0	0
电缆 及 电缆组 件	×	0	×	×	0	0
塑料和聚合物部件	0	0	0	0	0	X

表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006标准规定的限量要求以下。

表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006 标准规定的限量要求。

The Disclosure Table is intended only to communicate compliance with China requirements; it is not intended to communicate compliance with EU RoHS or any other environmental requirements.

RF Exposure Separation Distances

To protect from overexposure to radio frequency (RF) energy, install Cambium radios so as to provide and maintain the minimum separation distances from all persons shown in Table 35.

 Table 42
 Exposure separation distances

Module Type	Separation Distance from Persons		
Radio Module with integrated antenna	At least 20 cm (approx 8 in)		
Module with Reflector Dish	At least 1.5 m (approx 60 in or 5 ft)		
Module with LENS	At least 0.5 m (approx 20 in)		
Antenna of connectorized 5.7 GHz AP	At least 30 cm (approx 12 in)		
Antenna of connectorized or integrated 900 MHz module	At least 60 cm (24 in)		
Indoor 900 MHz SM	At least 10 cm (4 in)		
PMP 320 AP	At least 50 cm (20 in)		

For details and discussion of the associated calculations, see the Canopy System Release 9.4.2 User's Guide, available at http://www.cambiumnetworks.com/support

Legal Notices

Software License Terms and Conditions

ONLY OPEN THE PACKAGE, OR USE THE SOFTWARE AND RELATED PRODUCT IF YOU ACCEPT THE TERMS OF THIS LICENSE. BY BREAKING THE SEAL ON THIS DISK KIT / CDROM, OR IF YOU USE THE SOFTWARE OR RELATED PRODUCT, YOU ACCEPT THE TERMS OF THIS LICENSE AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, DO NOT USE THE SOFTWARE OR RELATED PRODUCT; INSTEAD, RETURN THE SOFTWARE TO PLACE OF PURCHASE FOR A FULL REFUND. THE FOLLOWING AGREEMENT IS A LEGAL AGREEMENT BETWEEN YOU (EITHER AN INDIVIDUAL OR ENTITY), AND CAMBIUM, INC. (FOR ITSELF AND ITS LICENSORS). THE RIGHT TO USE THIS PRODUCT IS LICENSED ONLY ON THE CONDITION THAT YOU AGREE TO THE FOLLOWING TERMS.

Now, therefore, in consideration of the promises and mutual obligations contained herein, and for other good and valuable consideration, the receipt and sufficiency of which are hereby mutually acknowledged, you and Cambium agree as follows:

Grant of License. Subject to the following terms and conditions, Cambium, Inc., grants to you a personal, revocable, non-assignable, non-transferable, non-exclusive and limited license to use on a single piece of equipment only one copy of the software contained on this disk (which may have been pre-loaded on the equipment) (Software). You may make two copies of the Software, but only for backup, archival, or disaster recovery purposes. On any copy you make of the Software, you must reproduce and include the copyright and other proprietary rights notice contained on the copy we have furnished you of the Software.

Ownership. Cambium (or its supplier) retains all title, ownership and intellectual property rights to the Software and any copies, including translations, compilations, derivative works (including images) partial copies and portions of updated works. The Software is Cambium's (or its supplier's) confidential proprietary information. This Software License Agreement does not convey to you any interest in or to the Software, but only a limited right of use. You agree not to disclose it or make it available to anyone without Cambium's written authorization. You will exercise no less than reasonable care to protect the Software from unauthorized disclosure. You agree not to disassemble, decompile or reverse engineer, or create derivative works of the Software, except and only to the extent that such activity is expressly permitted by applicable law.

Termination. This License is effective until terminated. This License will terminate immediately without notice from Cambium or judicial resolution if you fail to comply with any provision of this License. Upon such termination you must destroy the Software, all accompanying written materials and all copies thereof, and the sections entitled Limited Warranty, Limitation of Remedies and Damages, and General will survive any termination.

Limited Warranty. Cambium warrants for a period of ninety (90) days from Cambium's or its customer's shipment of the Software to you that (i) the disk(s) on which the Software is recorded will be free from defects in materials and workmanship under normal use and (ii) the Software, under normal use, will perform substantially in accordance with Cambium's published specifications for that release level of the Software. The written materials are provided "AS IS" and without warranty of any kind. Cambium's entire liability and your sole and exclusive remedy for any breach of the foregoing limited warranty will be, at Cambium's option, replacement of the disk(s), provision of downloadable patch or replacement code, or refund of the unused portion of your bargained for contractual benefit up to the amount paid for this Software License.

THIS LIMITED WARRANTY IS THE ONLY WARRANTY PROVIDED BY CAMBIUM, AND CAMBIUM AND ITS LICENSORS EXPRESSLY DISCLAIM ALL OTHER WARRANTIES, EITHER EXPRESS OF IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. CAMBIUM DOES NOT WARRANT THAT THE OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERRORFREE, OR THAT DEFECTS IN THE SOFTWARE WILL BE CORRECTED. NO ORAL OR WRITTEN REPRESENTATIONS MADE BY CAMBIUM OR AN AGENT THEREOF SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY. CAMBIUM DOES NOT WARRANT ANY SOFTWARE THAT HAS BEEN OPERATED IN EXCESS OF SPECIFICATIONS, DAMAGED, MISUSED, NEGLECTED, OR IMPROPERLY INSTALLED. BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF IMPLIED WARRANTIES, THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

Limitation of Remedies and Damages. Regardless of whether any remedy set forth herein fails of its essential purpose, IN NO EVENT SHALL CAMBIUM OR ANY OF THE LICENSORS, DIRECTORS, OFFICERS, EMPLOYEES OR AFFILIATES OF THE FOREGOING BE LIABLE TO YOU FOR ANY CONSEQUENTIAL, INCIDENTAL, INDIRECT, SPECIAL OR SIMILAR DAMAGES WHATSOEVER (including, without limitation, damages for loss of business profits, business interruption, loss of business information and the like), whether foreseeable or unforeseeable, arising out of the use or inability to use the Software or accompanying written materials, regardless of the basis of the claim and even if Cambium or a Cambium representative has been advised of the possibility of such damage. Cambium's liability to you for direct damages for any cause whatsoever, regardless of the basis of the form of the action, will be limited to the price paid for the Software that caused the damages. THIS LIMITATION WILL NOT APPLY IN CASE OF PERSONAL INJURY ONLY WHERE AND TO THE EXTENT THAT APPLICABLE LAW REQUIRES SUCH LIABILITY. BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

Maintenance and Support. Cambium shall not be responsible for maintenance or support of the software. By accepting the license granted under this agreement, you agree that Cambium will be under no obligation to provide any support, maintenance or service in connection with the Software or any application developed by you. Any maintenance and support of the Related Product will be provided under the terms of the agreement for the Related Product.

Transfer. In the case of software designed to operate on Cambium equipment, you may not transfer the Software to another party except: (1) if you are an end-user, when you are transferring the Software together with the Cambium equipment on which it operates; or 2) if you are a Cambium licensed distributor, when you are transferring the Software either together with such Cambium equipment or are transferring the Software as a licensed duly paid for upgrade, update, patch, new release, enhancement or replacement of a prior version of the Software. If you are a Cambium licensed distributor, when you are transferring the Software as permitted herein, you agree to transfer the Software with a license agreement having terms and conditions no less restrictive than those contained herein. You may transfer all other Software, not otherwise having an agreed restriction on transfer, to another party. However, all such transfers of Software are strictly subject to the conditions precedent that the other party agrees to accept the terms and conditions of this License, and you destroy any copy of the Software you do not transfer to that party. You may not sublicense or otherwise transfer, rent or lease the Software without our written consent. You may not transfer the Software in violation of any laws, regulations, export controls or economic sanctions imposed by the US Government.

Right to Audit. Cambium shall have the right to audit annually, upon reasonable advance notice and during normal business hours, your records and accounts to determine compliance with the terms of this Agreement.

Export Controls. You specifically acknowledge that the software may be subject to United States and other country export control laws. You shall comply strictly with all requirements of all applicable export control laws and regulations with respect to all such software and materials.

US Government Users. If you are a US Government user, then the Software is provided with "RESTRICTED RIGHTS" as set forth in subparagraphs (c)(1) and (2) of the Commercial Computer Software-Restricted Rights clause at FAR 52 227-19 or subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013, as applicable.

Disputes. You and Cambium hereby agree that any dispute, controversy or claim, except for any dispute, controversy or claim involving intellectual property, prior to initiation of any formal legal process, will be submitted for non-binding mediation, prior to initiation of any formal legal process. Cost of mediation will be shared equally. Nothing in this Section will prevent either party from resorting to judicial proceedings, if (i) good faith efforts to resolve the dispute under these procedures have been unsuccessful, (ii) the dispute, claim or controversy involves intellectual property, or (iii) interim relief from a court is necessary to prevent serious and irreparable injury to that party or to others.

General. Illinois law governs this license. The terms of this license are supplemental to any written agreement executed by both parties regarding this subject and the Software Cambium is to license you under it, and supersedes all previous oral or written communications between us regarding the subject except for such executed agreement. It may not be modified or waived except in writing and signed by an officer or other authorized representative of each party. If any provision is held invalid, all other provisions shall remain valid, unless such invalidity would frustrate the purpose of our agreement. The failure of either party to enforce any rights granted hereunder or to take action against the other party in the event of any breach hereunder shall not be deemed a waiver by that party as to subsequent enforcement of rights or subsequent action in the event of future breaches.

Hardware Warranty in U.S.

Cambium's standard hardware warranty is for one (1) year from date of shipment from Cambium or a Cambium distributor. Cambium warrants that hardware will conform to the relevant published specifications and will be free from material defects in material and workmanship under normal use and service. Cambium shall within this time, at its own option, either repair or replace the defective product within thirty (30) days of receipt of the defective product. Repaired or replaced product will be subject to the original warranty period but not less than thirty (30) days. For warranty assistance, contact the reseller or distributor.

A CAUTION

Using non-Cambium parts for repair could damage the equipment or void warranty. Contact Cambium for service and repair instructions.

⚠ CAUTION

Portions of Cambium equipment may be damaged from exposure to electrostatic discharge. Use precautions to prevent damage.

Limit of Liability

IN NO EVENT SHALL CAMBIUM BE LIABLE TO YOU OR ANY OTHER PARTY FOR ANY DIRECT, INDIRECT, GENERAL, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR OTHER DAMAGE ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION OR ANY OTHER PECUNIARY LOSS, OR FROM ANY BREACH OF WARRANTY, EVEN IF CAMBIUM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. (Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.) IN NO CASE SHALL CAMBIUM'S LIABILITY EXCEED THE AMOUNT YOU PAID FOR THE PRODUCT.


Chapter 6: UGPS Regulatory, Legal, and Safety Notices

IMPORTANT NOTE ON MODIFICATIONS

Intentional or unintentional changes or modifications to the equipment must not be made unless under the express consent of the party responsible for compliance. Any such modifications could void the user's authority to operate the equipment and voids the manufacturer's warranty.

Universal GPS module label

Figure 99 UGPS label



NATIONAL AND REGIONAL REGULATORY NOTICES

U.S. Federal Communication Commission (FCC) Notification

This device complies with Part 15 of the US FCC Rules and Regulations. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the US FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to correct the interference by one or more of the following measures:

- Increase the separation between the affected equipment and the unit;
- Connect the affected equipment to a power outlet on a different circuit from that which the receiver is connected to;
- Consult the dealer and/or experienced radio/TV technician for help.

Equipment Disposal

Figure 100 Waste disposal of electronic and electric equipment



Please do not dispose of Electronic and Electric Equipment or Electronic and Electric Accessories with your household waste. In some countries or regions, collection systems have been set up to handle waste of electrical and electronic equipment. In European Union countries, please contact your local equipment supplier representative or service center for information about the waste collection system in your country.

LIMIT OF LIABILITY

IN NO EVENT SHALL CAMBIUM NETWORKS BE LIABLE TO YOU OR ANY OTHER PARTY FOR ANY DIRECT, INDIRECT, GENERAL, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR OTHER DAMAGE ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION OR ANY OTHER PECUNIARY LOSS, OR FROM ANY BREACH OF WARRANTY, EVEN IF CAMBIUM NETWORKS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. (Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.) IN NO CASE SHALL CAMBIUM NETWORKS LIABILITY EXCEED THE AMOUNT YOU PAID FOR THE PRODUCT.