

The following fields are available in the **Save Configuration** window:

Field	Description
Save Option	Specifies the save option to be used for the Switch.
Transfer Mode	The transfer mechanism to save the Switch configurations in the remote system.
Address Type	The IP Address type of the remote system in which the Switch configurations are to be saved.
IP Address	The IP Address of the remote system in which the Switch configurations are to be saved.
SFTP User Name	The user name required for saving the Switch configurations to the remote system in SFTP mode.
SFTP Password	The password required for saving the Switch configurations on to the remote system in SFTP mode.
File Name	The name of the file in which the Switch configurations are to be saved.

The following fields are available in the **Restore Configuration** window:

Field	Description
Restore Option	Specifies whether the Switch configurations have to be restored.

The following fields are available in the **Erase Configuration** window:

Field	Description
Erase Option	Specifies the erase or delete configuration or file.
File Name	The configuration flash file name to be erased.